

H8DSP-8 H8DSP-i

USER'S MANUAL

Revision 1.0a

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates.

The manufacturer reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software, if any, and documentation may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any medium or machine without prior written consent.

IN NO EVENT WILL THE MANUFACTURER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, THE VENDOR SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. The manufacturer's total liability for all claims will not exceed the price paid for the hardware product.

Manual Revision 1.0a

Release Date: March 17, 2006

Unless you request and receive written permission from the manufacturer, you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2006
All rights reserved.

Printed in the United States of America

Preface

About This Manual

This manual is written for system integrators, PC technicians and knowledgeable PC users. It provides information for the installation and use of the H8DSP-8/H8DSP-i serverboard. The H8DSP-8/H8DSP-i is based on the ServerWorks HT-2000/1000 chipset and supports single or dual AMD Opteron processors (single or dual core) in 940-pin microPGA ZIF sockets and up to 32 GB of DDR333/266 or 16 GB of DDR400.

Please refer to the serverboard specifications pages on our web site for updates on supported processors. This product is intended to be professionally installed.

Manual Organization

Chapter 1 includes a checklist of what should be included in your serverboard box, describes the features, specifications and performance of the serverboard and provides detailed information about the chipset.

Chapter 2 begins with instructions on handling static-sensitive devices. Read this chapter when installing the processor(s) and memory modules and when installing the serverboard in a chassis. Also refer to this chapter to connect the floppy and hard disk drives, the serial ports, the mouse and keyboard and the twisted wires for the power and reset buttons and the system LEDs.

If you encounter any problems, see **Chapter 3**, which describes troubleshooting procedures for the video, the memory and the setup configuration stored in CMOS. For quick reference, a general FAQ (Frequently Asked Questions) section is provided. Instructions are also included for contacting technical support. In addition, you can visit our web site for more detailed information.

Chapter 4 includes an introduction to BIOS and provides detailed information on running the CMOS Setup utility.

Appendix A provides BIOS Error Beep Code Messages.

Appendix B lists BIOS POST Checkpoint Codes.

Table of Contents

Preface

| | |
|---------------------------|-----|
| About This Manual | iii |
| Manual Organization | iii |

Chapter 1: Introduction

| | |
|--|------|
| 1-1 Overview | 1-1 |
| Checklist | 1-1 |
| H8DSP-8/H8DSP-i Image | 1-3 |
| H8DSP-8/H8DSP-i Serverboard Layout | 1-4 |
| H8DSP-8/H8DSP-i Quick Reference | 1-5 |
| Serverboard Features | 1-6 |
| ServerWorks HT-200/100 Chipset: System Block Diagram | 1-8 |
| 1-2 Chipset Overview | 1-9 |
| 1-3 PC Health Monitoring | 1-10 |
| 1-4 Power Configuration Settings | 1-11 |
| 1-5 Power Supply | 1-12 |
| 1-6 Super I/O | 1-13 |

Chapter 2: Installation

| | |
|---|------|
| 2-1 Static-Sensitive Devices | 2-1 |
| 2-2 Processor and Heatsink Installation | 2-2 |
| 2-3 Mounting the Serverboard into a Chassis | 2-4 |
| 2-4 Installing Memory | 2-4 |
| 2-5 I/O Port and Control Panel Connections | 2-7 |
| 2-6 Connecting Cables | 2-8 |
| Primary ATX Power Supply Connector | 2-8 |
| Secondary Power Connector | 2-8 |
| NMI Button | 2-8 |
| Power LED | 2-8 |
| HDD LED | 2-9 |
| NIC1 LED | 2-9 |
| NIC2 LED | 2-9 |
| Overheat/Fan Fail LED | 2-9 |
| Power Fail LED | 2-10 |
| UID Button and LED | 2-10 |
| Power Button | 2-10 |
| Universal Serial Bus Ports (USB0/1) | 2-10 |

| | |
|--|------|
| USB2/3 Headers | 2-11 |
| Serial Ports | 2-11 |
| Fan Headers | 2-11 |
| Overheat LED | 2-11 |
| Chassis Intrusion | 2-11 |
| Power LED/Speaker | 2-12 |
| ATX PS/2 Keyboard/Mouse Ports | 2-12 |
| JLAN1/2 (Ethernet Ports) | 2-12 |
| IPMB Header | 2-12 |
| DOC Power Header | 2-13 |
| Wake-On-Ring | 2-13 |
| Wake-On-LAN | 2-13 |
| 2-7 Jumper Settings | 2-14 |
| Explanation of Jumpers | 2-14 |
| CMOS Clear | 2-14 |
| PCI-X#1/PCI-X#2 Frequency Select | 2-15 |
| Onboard Speaker Enable/Disable | 2-15 |
| Watch Dog Enable/Disable | 2-15 |
| SCSI Controller Enable/Disable | 2-16 |
| SCSI Termination Enable/Disable | 2-16 |
| VGA Enable/Disable | 2-16 |
| Power Force On | 2-16 |
| I ² C to PCI Enable/Disable | 2-17 |
| DOC IDE Bus Select | 2-17 |
| 2-8 Onboard Indicators | 2-17 |
| JLAN1/2 LEDs | 2-17 |
| +3.3V Power LED | 2-17 |
| SCSI Activity LEDs | 2-18 |
| POST Code LEDs | 2-18 |
| 2-9 Floppy, IDE, SCSI and SATA Drive Connections | 2-19 |
| Floppy Connector | 2-19 |
| IDE Connectors | 2-20 |
| SCSI Connectors | 2-21 |
| SATA Connector | 2-22 |
| Chapter 3: Troubleshooting | |
| 3-1 Troubleshooting Procedures | 3-1 |
| Before Power On | 3-1 |

| | |
|---|-----|
| No Power | 3-1 |
| No Video | 3-1 |
| Memory Errors | 3-2 |
| Losing the System's Setup Configuration | 3-2 |
| 3-2 Technical Support Procedures | 3-2 |
| 3-3 Frequently Asked Questions | 3-3 |
| 3-4 Returning Merchandise for Service | 3-4 |

Chapter 4: BIOS

| | |
|----------------------------------|------|
| 4-1 Introduction | 4-1 |
| 4-2 Main Setup | 4-2 |
| 4-3 Advanced Settings Menu | 4-2 |
| 4-4 PCI/PnP Menu | 4-10 |
| 4-5 Boot Menu | 4-11 |
| 4-6 Security Menu | 4-14 |
| 4-7 Chipset Menu | 4-15 |
| 4-8 Exit Menu | 4-17 |

Appendices:

| | |
|--|-----|
| Appendix A: BIOS Error Beep Codes | A-1 |
| Appendix B: BIOS POST Checkpoint Codes | B-1 |

Chapter 1

Introduction

1-1 Overview

Checklist

Congratulations on purchasing your computer serverboard from an acknowledged leader in the industry. Our boards are designed with the utmost attention to detail to provide you with the highest standards in quality and performance.

Please check that the following items have all been included with your serverboard. If anything listed here is damaged or missing, contact your retailer.


- One (1) H8DSP-8 or H8DSP-i serverboard
- One (1) IDE cable (CBL-036)
- One (1) floppy cable (CBL-022)
- One (1) CD containing drivers, utilities and user's manual

Optional:

- Two (2) 1U passive heatsinks (SNK-P0012)
- Two (2) CPU backplates (BKT-0004)
- Two (2) heatsink retention modules (BKT-0005)


Notes

Figure 1-1. H8DSP-8/H8DSP-i Image



Note: the H8DSP-8 is pictured. The H8DSP-i shares the same layout but without SCSI controllers, jumpers or connectors.

Figure 1-2. H8DSP-8/H8DSP-i Serverboard Layout
(not drawn to scale)



Notes:

Jumpers not indicated are for test purposes only.
The H8DSP-i shares the same layout but without SCSI controllers, jumpers or connectors.

H8DSP-8/H8DSP-i Quick Reference

| Jumpers | Description | Default Setting |
|---------------------|--|------------------------|
| JBT1 | CMOS Clear | See Section 2-7 |
| JD1 | Onboard Spkr En/Disable | Pins 6-7 (Enabled) |
| J ² C1/2 | I ² C to PCI Enable/Disable | Closed (Enabled) |
| JP17 | DOC Bus Select | Closed (Master) |
| JPA1* | SCSI Enable/Disable | Pins 1-2 (Enabled) |
| JPA2/JPA3* | SCSI Channel A/B Term. | Open (Enabled) |
| JPF | Power Force On | Open (Normal) |
| JPG1 | VGA Enable/Disable | Pins 1-2 (Enabled) |
| JPXAO/JPXBO | PCI-X#1/#2 Freq. Select | Open (Auto) |
| JWD1 | Watch Dog | Pins 1-2 (Reset) |

| Connectors | Description |
|-------------------|--|
| 1U IPMI | IPMI 2.0 Socket |
| COM1/COM2 | COM1/2 Serial Port/Header |
| FAN1/2 - 9/10 | Fan Headers |
| J15 | Secondary Power Connector |
| J22 | System Management Bus (IPMB) Header |
| J43 | Primary ATX Power Connector (proprietary) |
| JA1* | Ultra320 SCSI Channel A Connector |
| JB1* | Ultra320 SCSI Channel B Connector |
| JD1 | Power LED/Speaker Header |
| JF1 | Front Panel Headers |
| JFDD1 | Floppy Disk Drive Connector |
| JIDE#1 | IDE#1 Connector |
| JL1 | Chassis Intrusion Header |
| JLAN1/2 | Gigabit Ethernet (RJ45) Ports |
| JSLED | SCSI LED Activity Header |
| JSM1 | 4-Port Serial ATA Connector (SATA0/1/2/3) |
| JWF1 | DOC Power Header |
| JWOL1 | Wake-On-LAN Header |
| JWOR | Wake-On-Ring Header |
| USB0/1/2/3 | Universal Serial Bus Ports (0/1) and Headers (2/3) |
| VGA | Video (Monitor) Port |

| Onboard LEDs | Description |
|---------------------|----------------------------------|
| DA1/DA2 | SCSI Channel A/B Activity LEDs |
| DB1-DB8 | POST Code LEDs |
| DP1 | +3.3V Standby Power LED |
| JPB1 | UID (Unit Identifier) LED/Button |

*H8DSP-8 only

Serverboard Features

CPU

- Single or dual AMD Opteron 200 series 64-bit processors in 940-pin microPGA ZIF sockets

Memory

- Eight dual/single channel DIMM slots supporting up to 32 GB of registered ECC DDR333/266 or up to 16 GB of registered ECC DDR400 SDRAM

Note: Memory capacities are halved for single CPU systems. Refer to Section 2-4 before installing.

Chipset

- ServerWorks HT-2000/1000

Expansion Slots

- One (1) 64-bit, 133 MHz PCI-X slot (3.3V)
- One (1) 64-bit, 100 MHz PCI-X/PCI slot (3.3V) (ZCR supported)
- Two (2) x8 PCI-Express slots

BIOS

- 8 Mb Firmware Hub AMIBIOS® Flash ROM
- APM 1.2, DMI 2.3, PCI 2.2, ACPI 1.0 (ACPI 2.0 is BIOS supported), Plug and Play (PnP)

PC Health Monitoring

- Onboard monitors for CPU core voltages, 2.5V, 5Vin, +1.2V, $\pm 12V$, 5V stby, 2.5V stby, DDR voltages and battery voltage
- Fan status monitor with firmware/software speed control in BIOS
- Watch Dog, NMI
- Environmental temperature monitoring via BIOS
- Power-up mode control for recovery from AC power loss
- System resource alert
- Hardware BIOS virus protection
- Auto-switching voltage regulator for the CPU core

ACPI Features

- Microsoft OnNow
- Slow blinking LED for suspend state indicator
- BIOS support for USB keyboard
- Main switch override mechanism
- Internal/external modem ring-on

Onboard I/O

- Adaptec AIC-7902W SCSI controller for dual-channel Ultra320 SCSI, RAID 0, 1, 10 and JBOD supported (H8DSP-8 only)
- On-chip (HT-1000) controller for 4-port SATA subsystem, RAID 0, 1, and 10 supported
- One (1) ATA100 IDE port
- One (1) floppy port interface (up to 2.88 MB)
- Two (2) Fast UART 16550 compatible serial connectors (1 header, 1 port)
- Embedded (on-chip) Ethernet controller supports two Gigabit LAN ports
- PS/2 mouse and PS/2 keyboard ports
- Four (4) USB 2.0 ports (two ports, two headers)
- ATI Rage 8 MB XL graphics chip
- VGA port

Other


- Wake-on-Ring (JWOR)
- Wake-on-LAN (JWOL1)

CD Utilities

- BIOS flash upgrade utility

Dimensions

- Proprietary form factor, 16.235" x 11.24" (412 x 285 mm)



**Figure 1-3. ServerWorks HT-2000/1000™ Chipset:
System Block Diagram**

Note: This is a general block diagram and may not exactly represent the features on your serverboard. See the previous pages for the actual specifications of your serverboard.

1-2 Chipset Overview

The H8DSP-8/H8DSP-i serverboard is based on a Serverworks' chipset composed of two main components: the HT-2000 HyperTransport™ SystemI/O™ controller and the HT-1000 HyperTransport™ SystemI/O™ Hub. The HT-2000/1000 chipset provides high performance, scalability and reliability. Its HyperTransport architecture reduces IO bottlenecks to improve overall system performance. System memory controllers are integrated into the processors to decrease latency.

HT-2000 SystemI/O™ Controller

The HT-2000 represents Serverworks' seventh generation of SystemI/O products. This controller hub connects to the processors over a 1GHz (Double Data Rate results in 2GHz operation), 16x HyperTransport bus and integrates the PCI-Express, PCI-X and Gigabit Ethernet. The HyperTransport architecture allows concurrency between the HyperTransport bus and PCI-Express and PCI-X. The processor side of the HT link supports transfer rates of 2000, 1600, 1000, 800 and 400 Mb/s.

HT-1000 HyperTransport I/O Hub

The HT-1000 I/O hub interconnects the CPU/host bridge with the I/O bridge via a HyperTransport bus to provide an interface between the HT-2000 and various subsystems including the Winbond Super I/O functions, the onboard graphics, the IDE controller and the USB ports.

HyperTransport Technology

HyperTransport technology is a high-speed, low latency point to point link that was designed to increase the communication speed by a factor of up to 48x between integrated circuits. This is done partly by reducing the number of buses in the chipset to reduce bottlenecks and by enabling a more efficient use of memory in multi-processor systems. The end result is a significant increase in bandwidth within the chipset.

1-3 PC Health Monitoring

This section describes the PC health monitoring features of the H8DSP-8/H8DSP-i. The serverboard has an onboard System Hardware Monitor chip that supports PC health monitoring.

Onboard Voltage Monitors for the CPU core voltages, 2.5V, 5Vin, 1.2V, \pm 12V, 5V stby, 2.5V stby, DDR and Battery Voltages

The onboard voltage monitor will scan these voltages continuously. Once a voltage becomes unstable, it will give a warning or send an error message to the screen. Users can adjust the voltage thresholds to define the sensitivity of the voltage monitor. Real time readings of these voltage levels are all displayed in the System Health Monitor section of BIOS.

Fan Status Monitor with Firmware/Software Speed Control

The PC health monitor can check the RPM status of the cooling fans. The onboard fans are controlled by thermal management via BIOS.

CPU Overheat/Fan Fail LED and Control

This feature is available when the user enables the CPU overheat/Fan Fail warning function in the BIOS. This allows the user to define an overheat temperature. When this temperature is exceeded or when a fan failure occurs, then, the Overheat/Fan Fail warning LED is triggered.

Auto-Switching Voltage Regulator for the CPU Core

The 3-phase-switching voltage regulator for the CPU core can support up to 80A and auto-sense voltage IDs ranging from 0.875 V to 1.6V. This will allow the regulator to run cooler and thus make the system more stable.

1-4 Power Configuration Settings

This section describes the features of your serverboard that deal with power and power settings.

Microsoft OnNow

The OnNow design initiative is a comprehensive, system-wide approach to system and device power control. OnNow is a term for a PC that is always on but appears to be off and responds immediately to user or other requests.

Slow Blinking LED for Suspend-State Indicator

When the CPU goes into a suspend state, the chassis power LED will start blinking to indicate that the CPU is in suspend mode. When the user presses any key, the CPU will wake-up and the LED will automatically stop blinking and remain on.

BIOS Support for USB Keyboard

If a USB keyboard is the only keyboard in the system, it will function like a normal keyboard during system boot-up.

Main Switch Override Mechanism

When an ATX power supply is used, the power button can function as a system suspend button. When the user depresses the power button, the system will enter a SoftOff state. The monitor will be suspended and the hard drive will spin down. Depressing the power button again will cause the whole system to wake-up. During the SoftOff state, the ATX power supply provides power to keep the required circuitry in the system alive. In case the system malfunctions and you want to turn off the power, just depress and hold the power button for 4 seconds. The power will turn off and no power will be provided to the serverboard.

Wake-On-Ring Header (JWOR)

Wake-up events can be triggered by a device such as the external modem ringing when the system is in the SoftOff state. Note that external modem ring-on can only be used with an ATX 2.01 (or above) compliant power supply.

1-5 Power Supply

As with all computer products, a stable power source is necessary for proper and reliable operation. It is even more important for processors that have high CPU clock rates of 1 GHz and faster.

The H8DSP-8/H8DSP-i accommodates 12V ATX power supplies. Although most power supplies generally meet the specifications required by the CPU, some are inadequate. A 2 amp current supply on a 5V Standby rail is strongly recommended. Note that the power supply connectors on the H8DSP-8/H8DSP-i are of a proprietary design and require a proprietary power supply for proper connection.

It is strongly recommended that you use a high quality power supply that meets 12V ATX power supply Specification 1.1 or above. Additionally, in areas where noisy power transmission is present, you may choose to install a line filter to shield the computer from noise. It is recommended that you also install a power surge protector to help avoid problems caused by power surges.

Warning: To prevent the possibility of explosion, do not use the wrong type of onboard CMOS battery or install it upside down.

1-6 Super I/O

The disk drive adapter functions of the Super I/O chip include a floppy disk drive controller that is compatible with industry standard 82077/765, a data separator, write pre-compensation circuitry, decode logic, data rate selection, a clock generator, drive interface control logic and interrupt and DMA logic. The wide range of functions integrated onto the Super I/O greatly reduces the number of components required for interfacing with floppy disk drives. The Super I/O supports two 360 K, 720 K, 1.2 M, 1.44 M or 2.88 M disk drives and data transfer rates of 250 Kb/s, 500 Kb/s or 1 Mb/s.

It also provides two high-speed, 16550 compatible serial communication ports (UARTs), one of which supports serial infrared communication. Each UART includes a 16-byte send/receive FIFO, a programmable baud rate generator, complete modem control capability and a processor interrupt system. Both UARTs provide legacy speed with baud rate of up to 115.2 Kbps as well as an advanced speed with baud rates of 250 K, 500 K, or 1 Mb/s, which support higher speed modems.

The Super I/O provides functions that comply with ACPI (Advanced Configuration and Power Interface), which includes support of legacy and ACPI power management through a SMI or SCI function pin. It also features auto power management to reduce power consumption.

The IRQs, DMAs and I/O space resources of the Super I/O can be flexibly adjusted to meet ISA PnP requirements, which support ACPI and APM (Advanced Power Management).

Notes

Chapter 2

Installation

2-1 Static-Sensitive Devices

Electric Static Discharge (ESD) can damage electronic components. To prevent damage to your system board, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the board from the antistatic bag.
- Handle the board by its edges only; do not touch its components, peripheral chips, memory modules or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the serverboard and peripherals back into their antistatic bags when not in use.
- For grounding purposes, make sure your computer chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the serverboard.
- Use only the correct type of CMOS onboard battery as specified by the manufacturer. Do not install the CMOS onboard battery upside down, which may result in a possible explosion.

Unpacking

The serverboard is shipped in antistatic packaging to avoid static damage. When unpacking the board, make sure the person handling it is static protected.

Installation Procedures

Follow the procedures as listed below to install the serverboard into a chassis:

1. Install the processor(s) and the heatsink(s).
2. Install the serverboard in the chassis.
3. Install the memory and add-on cards.
4. Finally, connect the cables and install the drivers.

2-2 Processor and Heatsink Installation



Exercise extreme caution when handling and installing the processor. Always connect the power cord last and always remove it before adding, removing or changing any hardware components.

Installing the CPU Backplates

Two CPU backplates (BKT-0004) are optional items that may be included in the retail box. The backplates prevent the CPU area of the serverboard from bending and provide a base for attaching the heatsink retention modules. To install, begin by peeling off the release paper to expose the adhesive. On the underside of the serverboard, locate the two holes on either side of the CPU socket. Attach the adhesive side of the backplate to the board by inserting the standoffs into the two holes and applying light pressure so that the backplate sticks to the underside of the board. Repeat for the second CPU socket. See Figure 2-1.

Installing the Processor (install to the CPU#1 socket first)

1. Lift the lever on CPU socket #1 until it points straight up.



2. Use your thumb and your index finger to hold the CPU. Locate pin 1 on the CPU socket and pin 1 on the CPU. Both are marked with a triangle.



3. Align pin 1 of the CPU with pin 1 of the socket. Once aligned, carefully place the CPU into the socket. *Do not drop the CPU on the socket, move the CPU horizontally or vertically or rub the CPU against the socket or against any pins of the socket, which may damage the CPU and/or the socket.*



4. With the CPU inserted into the socket, inspect the four corners of the CPU to make sure that it is properly installed and flush with the socket.

5. Gently press the CPU socket lever down until it locks in the plastic tab. For a dual-processor system, repeat these steps to install another CPU into the CPU#2 socket.


Note: if using a single processor, only CPU 1 DIMM slots are addressable.



Installing the Heatsink Retention Modules

Two heatsink retention modules (BKT-0005) and four screws are optional items that may be included in the retail box. Once installed, these are used to help attach the heatsinks to the CPUs. To install, position the module so that the CPU backplate standoffs insert through the holes on the heatsink retention module and the four feet on the module contact the serverboard. Secure the retention module to the backplate with two of the screws provided. See Figure 2-1. Repeat for the second CPU socket. **Note:** BKT-0005 is included for use with non-proprietary heatsinks only. When installing proprietary heatsinks, only BKT-0004 (CPU backplate) is needed. The BKT-0005 retention module was designed to provide compatibility with clip-and-cam type heatsinks from third parties.

Figure 2-1. CPU Backplate/Heatsink Retention Module Installation



Installing the Heatsink

We recommend the use of active type heatsinks (except for 1U systems). Connect the heatsink fans to a fan header near the CPU. To install the heatsinks, please follow the instructions included with your heatsink package (not included).

2-3 Mounting the Serverboard into a Chassis

All serverboards and motherboards have standard mounting holes to fit different types of chassis. Make sure that the locations of all the mounting holes for both the serverboard and the chassis match. Although a chassis may have both plastic and metal mounting fasteners, metal ones are highly recommended because they ground the serverboard to the chassis. Make sure that the metal standoffs click in or are screwed in tightly.

1. Check the compatibility of the serverboard ports and the I/O shield

The H8DSP-8/H8DSP-i serverboard requires a chassis that can support extended ATX boards 9.6" x 16.2" in size. Make sure that the I/O ports on the serverboard align with their respective holes in the I/O shield at the rear of the chassis.

2. Mounting the serverboard onto the mainboard tray in the chassis

Carefully mount the serverboard onto the mainboard tray by aligning the serverboard mounting holes with the raised metal standoffs in the tray. Insert screws into all the mounting holes in the serverboard that line up with the standoffs. Then use a screwdriver to secure the serverboard to the mainboard tray - tighten until just snug (if too tight you might strip the threads). Metal screws provide an electrical contact to the serverboard ground to provide a continuous ground for the system.

2-4 Installing Memory

CAUTION

Exercise extreme care when installing or removing memory modules to prevent any possible damage.

1. Insert each memory module vertically into its slot, paying attention to the notch along the bottom of the module to prevent inserting the module incorrectly (see Figure 2-2). See support information below.

2. Gently press down on the memory module until it snaps into place.

Notes: each processor has its own built-in memory controller, so CPU2 DIMMs cannot be addressed if only a single CPU is installed. 128 MB, 256 MB, 512 MB, 1 GB, 2 GB* and 4 GB* memory modules are supported.

*With Opteron 246 C-stepping CPUs and above.

It is highly recommended that you remove the power cord from the system before installing or changing any memory modules.

Support

The H8DSP-8/H8DSP-i supports single or dual-channel, registered ECC DDR400/333/266 SDRAM.

Both interleaved and non-interleaved memory are supported, so you may populate any number of DIMM slots (see note on previous page and charts on following page). The CPU2 DIMM slots can only be accessed when two CPUs are installed (however, the CPU2 DIMM slots are not required to be populated when two CPUs are installed).

Populating two adjacent slots at a time with memory modules of the same size and type will result in interleaved (128-bit) memory, which is faster than non-interleaved (64-bit) memory.


Optimizing memory performance

If two processors are installed, it is better to stagger pairs of DIMMs across both sets of CPU DIMM slots, e.g. first populate CPU1 slots 1A and 1B, then CPU2 slots 1A, and 1B, then the next two CPU1 slots, etc. This balances the load over both CPUs to optimize performance.

Maximum memory (two CPUs): 32 GB for DDR333/266 and 16 GB for DDR400.

If only one CPU is installed, maximum supported memory is halved (16 GB for DDR333/266 and 8 GB for DDR400).


Figure 2-2. Side and Top Views of DDR Installation



Note the notch in the slot and on the bottom of the DIMM. These prevent the DIMM from being installed incorrectly.

To Remove:

Use your thumbs to gently push each release tab outward to release the DIMM from the slot.



| Populating Memory Banks for 128-bit Operation | | | | | | | |
|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| CPU1 DIMM1A | CPU1 DIMM1B | CPU1 DIMM2A | CPU1 DIMM2B | CPU2 DIMM1A | CPU2 DIMM1B | CPU2 DIMM2A | CPU2 DIMM2B |
| X | X | | | | | | |
| X | X | | | X | X | | |
| X | X | | | | | X | X |
| X | X | | | X | X | X | X |
| X | X | X | X | | | | |
| X | X | X | X | X | X | | |
| X | X | X | X | | | X | X |
| X | X | X | X | X | X | X | X |
| | | X | X | | | | |
| | | X | X | X | X | | |
| | | X | X | | | X | X |
| | | X | X | X | X | X | X |


Notes: X indicates a populated DIMM slot. If adding at least four DIMMs (with two CPUs installed), the configurations with DIMMs spread over both CPUs (and not like the configuration in row 5) will result in optimized performance. Note that the first two DIMMs must be installed in the CPU1 memory slots.

| Populating Memory Banks for 64-bit Operation | | | | | | | |
|--|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| CPU1 DIMM1A | CPU1 DIMM1B | CPU1 DIMM2A | CPU1 DIMM2B | CPU2 DIMM1A | CPU2 DIMM1B | CPU2 DIMM2A | CPU2 DIMM2B |
| X | | | | | | | |
| | | X | | | | | |
| X | | X | | | | | |
| X | | | | X | | | |
| X | | | | | | X | |
| | | X | | X | | | |
| | | X | | | | X | |

2-5 I/O Port and Control Panel Connections

The I/O ports are color coded in conformance with the PC99 specification to make setting up your system easier. See Figure 2-3 below for the colors and locations of the various I/O ports.


Figure 2-3. I/O Port Locations and Definitions



Front Control Panel

JF1 contains header pins for various front control panel connectors. See Figure 2-4 for the pin definitions of the various connectors. Refer to Section 2-6 for details.

Figure 2-4. JF1: Front Control Panel Header



2-6 Connecting Cables

Primary ATX Power Supply Connector

The primary power supply connector (J43) on the H8DSP-8/H8DSP-i is a proprietary design with unique pinouts and requires the correct proprietary power supply to operate. Refer to the table on the right for the pin definitions of the J43 main power connector. You must also connect the J15 power connector to your power supply (see below).

| ATX Power 20-pin Connector Pin Definitions (J43) | | | |
|---|-------------------|-------|-------------------|
| Pin# | Definition | Pin # | Definition |
| 11 | Ground | 1 | Ground |
| 12 | +5V | 2 | Ground |
| 13 | +5V | 3 | Ground |
| 14 | +3.3V | 4 | Ground |
| 15 | +3.3V | 5 | Ground |
| 16 | +5VSB | 6 | Ground |
| 17 | +12V | 7 | Ground |
| 18 | +12V | 8 | +12V ₂ |
| 19 | +12V ₁ | 9 | +12V ₂ |
| 20 | NC | 10 | +12V ₁ |

Required Connection

Secondary Power Connector

In addition to the Primary ATX power connector (above), the 10-pin power connector at J15 must also be connected to your power supply. See the table on the right for pin definitions. Note that the pin arrangement is different than usual, with pins 1 and 2 on opposite sides.

| Secondary Power Connector Pin Definitions (J15) | | | |
|--|------------------------------|-------|------------|
| Pin# | Definition | Pin # | Definition |
| 1 | SMBus I ² C Clock | 2 | Ground |
| 3 | SMBus I ² C Data | 4 | Power Fail |
| 5 | Ground | 6 | Power Good |
| 7 | Power On | 8 | -12V |
| 9 | NC | 10 | No pin |

Required Connection

NMI Button

The non-maskable interrupt button header is located on pins 19 and 20 of JF1. Refer to the table on the right for pin definitions.

| NMI Button Pin Definitions (JF1) | |
|-------------------------------------|------------|
| Pin# | Definition |
| 19 | Control |
| 20 | Ground |

Power LED

The Power LED connection is located on pins 15 and 16 of JF1. Refer to the table on the right for pin definitions.

| Power LED Pin Definitions (JF1) | |
|------------------------------------|------------|
| Pin# | Definition |
| 15 | Vcc |
| 16 | Control |

HDD LED

The HDD (IDE Hard Disk Drive) LED connection is located on pins 13 and 14 of JF1. Attach the IDE hard drive LED cable to display disk activity. Refer to the table on the right for pin definitions.

| HDD LED Pin Definitions (JF1) | |
|----------------------------------|------------|
| Pin# | Definition |
| 13 | Vcc |
| 14 | HD Active |

NIC1 LED

The NIC1 (Network Interface Controller) LED connection is located on pins 11 and 12 of JF1. Attach the NIC1 LED cable to display network activity. Refer to the table on the right for pin definitions.

| NIC1 LED Pin Definitions (JF1) | |
|-----------------------------------|-------------|
| Pin# | Definition |
| 11 | Vcc |
| 12 | NIC1 Active |

NIC2 LED

The NIC2 (Network Interface Controller) LED connection is located on pins 9 and 10 of JF1. Attach the NIC2 LED cable to display network activity. Refer to the table on the right for pin definitions.

| NIC2 LED Pin Definitions (JF1) | |
|-----------------------------------|-------------|
| Pin# | Definition |
| 9 | Vcc |
| 10 | NIC2 Active |

Overheat/Fan Fail LED

Connect an LED to the OH connection on pins 7 and 8 of JF1 to provide advanced warning of chassis overheating. Refer to the table on the right for pin definitions.

| OH/Fan Fail LED Pin Definitions (JF1) | |
|--|------------|
| Pin# | Definition |
| 7 | Vcc |
| 8 | Control |

Power Fail LED

The Power Fail LED connection is located on pins 5 and 6 of JF1. See the table on the right for pin definitions.

Note: This feature is only available when using redundant power supplies.

| Power Fail LED Pin Definitions (JF1) | |
|---|------------|
| Pin# | Definition |
| 5 | Vcc |
| 6 | Control |

UID Button and LED

A Unit Identifier button/LED is located on pins 3 and 4 of JF1. Attach it to the hardware reset switch on the computer case. Refer to the table on the right for pin definitions.

| UID Button/LED Pin Definitions (JF1) | |
|---|------------|
| Pin# | Definition |
| 3 | UID Button |
| 4 | UID LED |

Power Button

The Power Button connection is located on pins 1 and 2 of JF1. Momentarily contacting both pins will power on/off the system. This button can also be configured to function as a suspend button (see the Power Button Mode setting in BIOS). To turn off the power when set to suspend mode, depress the button for at least 4 seconds. Refer to the table on the right for pin definitions.

| Power Button Pin Definitions (JF1) | |
|---------------------------------------|------------|
| Pin# | Definition |
| 1 | PW_ON |
| 2 | Ground |

USB0/1 (Universal Serial Bus Ports)

Two Universal Serial Bus ports (USB2.0) are located to the left of the LAN ports. See the table on the right for pin definitions.

| Universal Serial Bus Ports Pin Definitions (USB0/1) | | | |
|--|------------|-------|------------|
| USB0 | | USB1 | |
| Pin # | Definition | Pin # | Definition |
| 1 | +5V | 1 | +5V |
| 2 | PO- | 2 | PO- |
| 3 | PO+ | 3 | PO+ |
| 4 | Ground | 4 | Ground |

USB2/3 Headers

Two additional USB2.0 headers (USB2/3) are included on the serverboard. These may be connected to provide front side access. USB cables (not included) are needed for the connections. See the table on the right for pin definitions.

| Extra Universal Serial Bus Headers Pin Definitions (USB2/3) | | | |
|--|------------|--------|---------------|
| USB2 | | USB3/4 | |
| Pin # | Definition | Pin # | Definition |
| 1 | +5V | 1 | +5V |
| 2 | PO- | 2 | PO- |
| 3 | PO+ | 3 | PO+ |
| 4 | Ground | 4 | Ground |
| 5 | Key | 5 | No connection |

Serial Ports

The COM1 serial port is located between the keyboard and the LAN ports. COM2 is a header located near JD1. See the table on the right for pin definitions.

| Serial Port Pin Definitions (COM1/COM2) | | | |
|--|------------|-------|------------|
| Pin # | Definition | Pin # | Definition |
| 1 | CD | 6 | DSR |
| 2 | RD | 7 | RTS |
| 3 | TD | 8 | CTS |
| 4 | DTR | 9 | RI |
| 5 | Ground | 10 | NC |

Note: NC indicates no connection.

Fan Headers

The H8DSP/H8DSP-i has five fan headers, each of which support two 4-cm counter-rotating fans. Fan speed is controlled via Thermal Management with a BIOS setting. See the table on the right for pin definitions.

| Fan Header Pin Definitions (FAN1/2-9/10) | |
|--|-----------------|
| Pin# | Definition |
| 1 | FAN2 Power |
| 2 | FAN2 Tachometer |
| 3 | Ground |
| 4 | Ground |
| 5 | FAN1 Tachometer |
| 6 | FAN1 Power |

Chassis Intrusion

A Chassis Intrusion header is located at JL1. Attach the appropriate cable to inform you of a chassis intrusion.

| Chassis Intrusion Pin Definitions (JL1) | |
|--|-----------------|
| Pin# | Definition |
| 1 | Intrusion Input |
| 2 | Ground |

Power LED/Speaker

On JD1, pins 1, 2, and 3 are for the power LED and pins 4 through 7 are for the speaker. See the tables on the right for pin definitions.

Note: The speaker connector pins are for use with an external speaker. If you wish to use the onboard speaker, you should close pins 6 and 7 with a jumper.

| PWR LED Connector Pin Definitions (JD1) | |
|--|------------|
| Pin# | Definition |
| 1 | +Vcc |
| 2 | -Vcc |
| 3 | -Vcc |

| Speaker Connector Pin Definitions (JD1) | |
|--|------------------------|
| Pin# | Definition |
| 4 | Red wire, Speaker data |
| 5 | No connection |
| 6 | Buzzer signal |
| 7 | Speaker data |

ATX PS/2 Keyboard and PS/2 Mouse Ports

The ATX PS/2 keyboard and the PS/2 mouse ports are located between the COM1 and the LAN ports. See the table on the right for pin definitions.

| PS/2 Keyboard and Mouse Port Pin Definitions (KB/Mouse) | | | |
|---|------------|-------|------------|
| Pin # | Definition | Pin # | Definition |
| 1 | Data | 4 | VCC |
| 2 | NC | 5 | Clock |
| 3 | Ground | 6 | NC |

JLAN1/2 (Ethernet Ports)

Two Gigabit Ethernet ports (designated JLAN1 and JLAN2) are located beside the VGA port. These ports accept RJ45 type cables.



IPMB Header

The Intelligent Platform Management Bus (IPMB) header is located at J22. Connect the appropriate cable here to utilize IPMB on your system. See the table on the right for pin definitions.

| IPMB Pin Definitions (J22) | |
|-------------------------------|------------|
| Pin# | Definition |
| 1 | Data |
| 2 | Ground |
| 3 | Clock |
| 4 | N/A |

DOC Power Header

JWF1 is a power header for a DOC (Disk-On-Chip) device. Connect the appropriate cable here to provide power to a DOC device on your system. See the table on the right for pin definitions.

| DOC Power Header Pin Definitions (JWF1) | |
|--|------------|
| Pin# | Definition |
| 1 | +5V |
| 2 | Ground |
| 3 | Signal |

Wake-On-Ring

The Wake-On-Ring header is designated JWOR. This function allows your computer to receive and "wake-up" by an incoming call to the modem when in suspend state. See the table on the right for pin definitions. You must have a Wake-On-Ring card and cable to use this feature.

| Wake-On-Ring Pin Definitions (JWOR) | |
|---|----------------|
| Pin# | Definition |
| 1 | Ground (Black) |
| 2 | Wake-up |

Wake-On-LAN


The Wake-On-LAN header is designated JWOL1. See the table on the right for pin definitions. You must have a LAN card with a Wake-On-LAN connector and cable to use the Wake-On-LAN feature.

| Wake-On-LAN Pin Definitions (JWOL1) | |
|---|-------------|
| Pin# | Definition |
| 1 | +5V Standby |
| 2 | Ground |
| 3 | Wake-up |

2-7 Jumper Settings

Explanation of Jumpers

To modify the operation of the serverboard, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board. See the diagram at right for an example of jumping pins 1 and 2. Refer to the serverboard layout page for jumper locations.



Note 1: On two-pin jumpers, "Closed" means the jumper is on and "Open" means the jumper is off the pins.

CMOS Clear

JBT1 is used to clear CMOS and will also clear any passwords. Instead of pins, this jumper consists of contact pads to prevent accidentally clearing the contents of CMOS.

To clear CMOS,

- 1) First power down the system and unplug the power cord(s).
- 2) With the power disconnected, short the CMOS pads with a metal object such as a small screwdriver for at least four seconds.
- 3) Remove the screwdriver (or shorting device).
- 4) Reconnect the power cord(s) and power on the system.

Notes:

Do not use the PW_ON connector to clear CMOS.

The onboard battery does not need to be removed when clearing CMOS, however you must short JBT1 for at least four seconds.



JBT1 contact pads

PCI-X#1/#2 Frequency Select

Jumpers JXAO and JXBO are used to set the speed of PCI-X slots 1 and 2, respectively. The recommended (default) setting is open for Auto. See the table on the right for jumper settings.

| PCI-X#1/#2 Frequency Select Jumper Settings (JXAO/JXBO) | |
|--|--------------|
| Jumper Setting | Definition |
| Pins 1-2 | 66 MHz PCI-X |
| Pins 2-3 | 66 MHz PCI |
| Open | Auto |

Onboard Speaker Enable/Disable

The JD1 header allows you to use either an external speaker or the internal (onboard) speaker. To use the internal (onboard) speaker, close pins 6 and 7 with a jumper. To use an external speaker, connect the speaker wires to pins 4 through 7 of JD1. See the table on the right for settings and the table associated with the Power LED/Speaker connection (previous section) for pin definitions.

| Onboard Speaker Enable/Disable Pin Definitions (JD1) | |
|---|-------------------------------|
| Pins | Definition |
| 6-7 | Jump for onboard speaker |
| 4-7 | Attach external speaker wires |

Watch Dog Enable/Disable

JWD1 controls the Watch Dog function. Watch Dog is a system monitor that can reboot the system when a software application hangs. Pins 1-2 will cause WD to reset the system if an application has frozen. Pins 2-3 will generate a non-maskable interrupt signal for the application that is frozen. See the table on the right for jumper settings. Watch Dog must also be enabled in BIOS.

| Watch Dog Jumper Settings (JWD1) | |
|-------------------------------------|------------|
| Jumper Setting | Definition |
| Pins 1-2 | Reset |
| Pins 2-3 | NMI |
| Open | Disabled |

Note: When enabled, the user needs to write their own application software in order to disable the Watch Dog Timer.

SCSI Controller Enable/ Disable (H8DSP-8 only)

Jumper JPA1 is used to enable or disable the Adaptec AIC-7902W SCSI controller. The default setting is on pins 1-2 to enable SCSI. See the table on right for jumper settings.

| SCSI Enable/Disable Jumper Settings (JPA1) | |
|---|------------|
| Both Jumpers | Definition |
| Pins 1-2 | Enabled |
| Pins 2-3 | Disabled |

SCSI Termination Enable/ Disable (H8DSP-8 only)

Jumpers JPA2 and JPA3 are used to enable or disable termination for SCSI channels A and B, respectively. The default setting is open to enable termination. See the table on right for pin definitions.

| SCSI Term. Enable/Disable Jumper Settings (JPA2/JPA3) | |
|--|------------|
| Jumper Setting | Definition |
| Open | Enabled |
| Closed | Disabled |

Note: In order for the SCSI drives to function properly, please do not change the default setting (enabled) set by the manufacturer.)

VGA Enable/Disable

JPG1 allows you to enable or disable the VGA port. The default position is on pins 1 and 2 to enable VGA. See the table on the right for jumper settings.

| VGA Enable/Disable Jumper Settings (JPG1) | |
|--|------------|
| Jumper Setting | Definition |
| Pins 1-2 | Enabled |
| Pins 2-3 | Disabled |

Power Force On

JPF allows you to enable or disable the Power Force On function. If enabled, system power will always stay on. If disabled (the default setting), the user needs to depress the power button to power up the system.

| Power Force On Jumper Settings (JPF) | |
|---|------------|
| Jumper Setting | Definition |
| Closed | Force On |
| Open | Disabled |

I²C to PCI Enable/Disable

JI²C1/2 pair of jumpers allow you to connect the System Management Bus to any one of the PCI slots. The default setting is closed for both jumpers to enable the connection. Both connectors must have the same setting (JI²C1 is for data and JI²C2 is for the clock). See the table on right for jumper settings.

| I ² C to PCI Enable/Disable Jumper Settings (JI ² C1/JI ² C2) | |
|--|------------|
| Jumper Setting | Definition |
| Closed | Enabled |
| Open | Disabled |

DOC IDE Bus Select

Jumper JP17 allows the user to choose either master or slave mode for a DOC (Disk-On-Chip) device that has been plugged into the IDE slot. See the table on right for jumper settings.

| DOC IDE Bus Select Jumper Settings (JP17) | |
|---|------------|
| Jumper Setting | Definition |
| Open | Slave |
| Closed | Master |

2-8 Onboard Indicators

JLAN1/JLAN2 LEDs

The Ethernet ports (located beside the VGA port) have two LEDs. On each Gb LAN port, the right (yellow) LED indicates activity while the left (orange) LED indicates when there is a connection (link). See the table on the right for the functions associated with the left (connection) LED.

| JLAN Left LED (Connection Indicator) | |
|--------------------------------------|---------------|
| LED Color | Definition |
| Off | No Connection |
| Orange | Connection |

+3.3V Power LED

When illuminated, the DP1 LED indicates that power from the power supply is being supplied to the serverboard (DP1 indicates the presence of +3.3V). See the table on the right for DP1 LED states.

| +3.3V Power LED (DP1) | |
|-----------------------|---------------------------------|
| State | System Status |
| On | Power present on serverboard |
| Off | No power present on serverboard |


SCSI Activity LEDs (H8DSP-8 only)

There are two SCSI activity LEDs on the serverboard. When illuminated, DA1 indicates activity on SCSI channel A and DA2 indicates activity on SCSI channel B.

| SCSI Channel Activity LEDs (DA1/DA2) | |
|--------------------------------------|-----------------------|
| State | System Status |
| On | SCSI Channel Active |
| Off | SCSI Channel Inactive |

POST Code LEDs

Eight surface-mounted LEDs are located near one end of the 1UIPMI slot. These LEDs are used to provide POST code information. See the diagrams below for reading the LEDs and refer to Appendix B for a complete list of POST codes.




Reading the POST Code LEDs:

When on, each of the eight separate LEDs represent the value of the number shown beside it in the diagram on the left. Add up the numerical values of each illuminated LED in the DB5-DB8 column to get the high (left) digit and those in the DB1-DB4 column to get the low (right) digit of the corresponding POST code.

Example:

Example:



The example on the left indicates a hexadecimal POST code of C6. This is determined in the following manner:

DB1-DB4 (low digit): 4 + 2 = 6

DB5-DB8 (high digit): 8 + 4 = 12

(decimal 12 = hexadecimal C)

- = Illuminated LED (1)
- = Unilluminated LED (0)

| Decimal | Hexidecimal Equivalent |
|---------|------------------------|
| 0-9 | 0-9 |
| 10 | A |
| 11 | B |
| 12 | C |
| 13 | D |
| 14 | E |
| 15 | F |

2-9 Floppy, IDE, SCSI and SATA Drive Connections

Use the following information to connect the floppy and hard disk drive cables.

- The floppy disk drive cable has seven twisted wires.
- A red mark on a wire typically designates the location of pin 1.
- A single floppy disk drive ribbon cable has 34 wires and two connectors to provide for two floppy disk drives. The connector with twisted wires always connects to drive A, and the connector that does not have twisted wires always connects to drive B.
- The 80-wire ATA100 IDE hard disk drive cable that came with your system has two connectors to support two drives. The blue connector connects to the on-board IDE connector interface and the other connector(s) to your hard drive(s). Consult the documentation that came with your disk drive for details on actual jumper locations and settings for the hard disk drive.

Floppy Connector

The floppy connector is located beside the IDE#1 connector. See the table on the right for pin definitions.

| Floppy Drive Connector Pin Definitions (JFDD1) | | | |
|---|------------|-------|-----------------|
| Pin# | Definition | Pin # | Definition |
| 1 | GND | 2 | FDHDIN |
| 3 | GND | 4 | Reserved |
| 5 | Key | 6 | FDEDIN |
| 7 | GND | 8 | Index- |
| 9 | GND | 10 | Motor Enable |
| 11 | GND | 12 | Drive Select B- |
| 13 | GND | 14 | Drive Select A- |
| 15 | GND | 16 | Motor Enable |
| 17 | GND | 18 | DIR- |
| 19 | GND | 20 | STEP- |
| 21 | GND | 22 | Write Data- |
| 23 | GND | 24 | Write Gate- |
| 25 | GND | 26 | Track 00- |
| 27 | GND | 28 | Write Protect- |
| 29 | GND | 30 | Read Data- |
| 31 | GND | 32 | Side 1 Select- |
| 33 | GND | 34 | Diskette |

IDE Connectors

There are no jumpers to configure the onboard IDE connector. See the table on the right for pin definitions.

| IDE Drive Connectors Pin Definitions (JIDE#1) | | | |
|--|---------------|-------|---------------|
| Pin# | Definition | Pin # | Definition |
| 1 | Reset IDE | 2 | Ground |
| 3 | Host Data 7 | 4 | Host Data 8 |
| 5 | Host Data 6 | 6 | Host Data 9 |
| 7 | Host Data 5 | 8 | Host Data 10 |
| 9 | Host Data 4 | 10 | Host Data 11 |
| 11 | Host Data 3 | 12 | Host Data 12 |
| 13 | Host Data 2 | 14 | Host Data 13 |
| 15 | Host Data 1 | 16 | Host Data 14 |
| 17 | Host Data 0 | 18 | Host Data 15 |
| 19 | Ground | 20 | Key |
| 21 | DRQ3 | 22 | Ground |
| 23 | I/O Write | 24 | Ground |
| 25 | I/O Read | 26 | Ground |
| 27 | IOCHRDY | 28 | BALE |
| 29 | DACK3 | 30 | Ground |
| 31 | IRQ14 | 32 | IOCS16 |
| 33 | Addr1 | 34 | Ground |
| 35 | Addr0 | 36 | Addr2 |
| 37 | Chip Select 0 | 38 | Chip Select 1 |
| 39 | Activity | 40 | Ground |

SCSI Connectors (H8DSP-8 only)

Refer to the table at right for pin definitions for the Ultra320 SCSI connectors located at JA1 and JB1.

| Ultra320 SCSI Drive Connectors Pin Definitions (JA1/JB1) | | | |
|---|------------|-------|------------|
| Pin# | Definition | Pin # | Definition |
| 1 | +DB (12) | 35 | -DB (12) |
| 2 | +DB (13) | 36 | -DB (13) |
| 3 | +DB (14) | 37 | -DB (14) |
| 4 | +DB (15) | 38 | -DB (15) |
| 5 | +DB (P1) | 39 | -DB (P1) |
| 6 | +DB (0) | 40 | -DB (0) |
| 7 | +DB (1) | 41 | -DB (1) |
| 8 | +DB (2) | 42 | -DB (2) |
| 9 | +DB (3) | 43 | -DB (3) |
| 10 | +DB (4) | 44 | -DB (4) |
| 11 | +DB (5) | 45 | -DB (5) |
| 12 | +DB (6) | 46 | -DB (6) |
| 13 | +DB (7) | 47 | -DB (7) |
| 14 | +DB (P) | 48 | -DB (P) |
| 15 | Ground | 49 | Ground |
| 16 | DIFFSENS | 50 | Ground |
| 17 | TERMPWR | 51 | TERMPWR |
| 18 | TERMPWR | 52 | TERMPWR |
| 19 | Reserved | 53 | Reserved |
| 20 | Ground | 54 | Ground |
| 21 | +ATN | 55 | -ATN |
| 22 | Ground | 56 | Ground |
| 23 | +BSY | 57 | -BSY |
| 24 | +ACK | 58 | -ACK |
| 25 | +RST | 59 | -RST |
| 26 | +MSG | 60 | -MSG |
| 27 | +SEL | 61 | -SEL |
| 28 | +C/D | 62 | -C/D |
| 29 | +REQ | 63 | -REQ |
| 30 | +I/O | 64 | -I/O |
| 31 | +DB (8) | 65 | -DB (8) |
| 32 | +DB (9) | 66 | -DB (9) |
| 33 | +DB (10) | 67 | -DB (10) |
| 34 | +DB (11) | 68 | -DB (11) |

SATA Connector

There are no jumpers to configure the SATA connector. JSM1 is a 4-port connector that includes designations SATA0 through SATA3. See the table on the right for pin definitions. This is a four-port connector.

| SATA 4-Port Connector Pin Definitions (JSM1) | | | |
|---|------------|-------|------------|
| Pin# | Definition | Pin # | Definition |
| 1 | Ground | 2 | RXD+ |
| 3 | RXD- | 4 | Ground |
| 5 | TXD- | 6 | TXD+ |
| 7 | Ground | 8 | RX1+ |
| 9 | RX1- | 10 | Ground |
| 11 | TX1- | 12 | TX1+ |
| 13 | Ground | 14 | SB0 |
| 15 | SB1 | 16 | SB2 |
| 17 | SB3 | 18 | SB4 |
| 19 | SB5 | 20 | Ground |
| 21 | RX2+ | 22 | RX2- |
| 23 | Ground | 24 | TX2- |
| 25 | TX2+ | 26 | Ground |
| 27 | RX3+ | 28 | RX3- |
| 29 | Ground | 30 | TX3- |
| 31 | TX3+ | 32 | Ground |
| 33 | NC | 34 | NC |
| 35 | Ground | 36 | Ground |

Note: NC indicates no connection.

Chapter 3

Troubleshooting

3-1 Troubleshooting Procedures

Use the following procedures to troubleshoot your system. If you have followed all of the procedures below and still need assistance, refer to the 'Technical Support Procedures' and/or 'Returning Merchandise for Service' section(s) in this chapter. Always disconnect the AC power cord before adding, changing or installing any hardware components.

Before Power On

1. Check that the onboard Power LED is lit (DP1 on the serverboard).
2. Make sure that the 10-pin 12v power connector at J15 is connected to your power supply.
3. Make sure that no short circuits exist between the serverboard and chassis.
4. Disconnect all ribbon/wire cables from the serverboard, including those for the keyboard and mouse.
5. Remove all add-on cards.
6. Install a CPU and heatsink (making sure it is fully seated) and connect the chassis speaker and the power LED to the serverboard. Check all jumper settings as well.
7. Use the correct type of onboard CMOS battery as recommended by the manufacturer. To avoid possible explosion, do not install the CMOS battery upside down.

No Power

1. Make sure that no short circuits exist between the serverboard and the chassis.
2. Verify that all jumpers are set to their default positions.
3. Check that the 115V/230V switch on the power supply is properly set.
4. Turn the power switch on and off to test the system.
5. The battery on your serverboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.

No Video

1. If the power is on but you have no video, remove all the add-on cards and cables.
2. Use the speaker to determine if any beep codes exist. Refer to Appendix A for details on beep codes.

NOTE

If you are a system integrator, VAR or OEM, a POST diagnostics card is recommended. For I/O port 80h codes, refer to App. B.

Memory Errors

1. Make sure that the DIMM modules are properly and fully installed.
2. You should be using registered ECC DDR memory (see next page). Also, it is recommended that you use the same memory type and speed for all DIMMs in the system. See Section 2-4 for memory details and limitations.
3. Check for bad DIMM modules or slots by swapping modules between slots and noting the results.
4. Check the power supply voltage 115V/230V switch.

Losing the System's Setup Configuration

1. Make sure that you are using a high quality power supply. A poor quality power supply may cause the system to lose the CMOS setup information. Refer to Section 1-6 for details on recommended power supplies.
2. The battery on your serverboard may be old. Check to verify that it still supplies ~3VDC. If it does not, replace it with a new one.
3. If the above steps do not fix the setup configuration problem, contact your vendor for repairs.

3-2 Technical Support Procedures

Before contacting Technical Support, please take the following steps. Also, note that as a serverboard manufacturer, we do not sell directly to end-users, so it is best to first check with your distributor or reseller for troubleshooting services. They should know of any possible problem(s) with the specific system configuration that was sold to you.

1. Please review the 'Troubleshooting Procedures' and 'Frequently Asked Questions' (FAQs) sections in this chapter or see the FAQs on our web site before contacting Technical Support.
2. BIOS upgrades can be downloaded from our web site.

Note: Not all BIOS can be flashed depending on the modifications to the boot block code.

3. If you still cannot resolve the problem, include the following information when contacting us for technical support:

- Serverboard model and PCB revision number
- BIOS release date/version (this can be seen on the initial display when your system first boots up)
- System configuration

An example of a Technical Support form is posted on our web site.

4. Distributors: For immediate assistance, please have your account number ready when contacting our technical support department by e-mail.

3-3 Frequently Asked Questions

Question: What type of memory does my serverboard support?

Answer: The H8DSP-8/H8DSP-i supports up to 32 GB of registered ECC DDR333/266 or up to 16 GB of registered ECC DDR400 interleaved or non-interleaved SDRAM with two CPUs installed. With only one CPU installed the maximum memory support is halved. See Section 2-4 for details on installing memory.

Question: How do I update my BIOS?

Answer: It is recommended that you not upgrade your BIOS if you are not experiencing problems with your system. Updated BIOS files are located on our web site. Please check our BIOS warning message and the information on how to update your BIOS on our web site. Also, check the current BIOS revision and make sure it is newer than your current BIOS before downloading.

Select your mainboard model on the web page and download the corresponding BIOS file to your computer. Unzip the BIOS update file, in which you will find the readme.txt (flash instructions), the amiflash.exe (BIOS flash utility) and the BIOS image (xxx.rom) files. Copy these files to a bootable floppy disk, insert the disk into drive A and reboot the system. At the DOS prompt after rebooting, enter the command "amiflash" (without quotation marks) then type in the BIOS file that you want to update with (xxxx.rom).

Question: What's on the CD that came with my serverboard?

Answer: The supplied compact disc has quite a few drivers and programs that will greatly enhance your system. We recommend that you review the CD and install the applications you need. Applications on the CD include chipset drivers for Windows and security and audio drivers.

Question: Why can't I turn off the power using the momentary power on/off switch?

Answer: The instant power off function is controlled in BIOS by the Power Button Mode setting. When the On/Off feature is enabled, the serverboard will have instant off capabilities as long as the BIOS has control of the system. When the Standby or Suspend feature is enabled or when the BIOS is not in control such as during memory count (the first screen that appears when the system is turned on), the momentary on/off switch must be held for more than four seconds to shut down the system. This feature is required to implement the ACPI features on the serverboard.

3-4 Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

Chapter 4

BIOS

4-1 Introduction

This chapter describes the AMIBIOS™ Setup utility for the H8DSP-8/H8DSP-i. The AMI ROM BIOS is stored in a flash chip and can be easily upgraded using a floppy disk-based program.

Note: Due to periodic changes to the BIOS, some settings may have been added or deleted and might not yet be recorded in this manual. Please refer to the Manual Download area of our web site for any changes to BIOS that may not be reflected in this manual.

Starting the Setup Utility

To enter the BIOS Setup Utility, hit the <Delete> key while the system is booting-up. (In most cases, the <Delete> key is used to invoke the BIOS setup screen. There are a few cases when other keys are used, such as <F1>, <F2>, etc.) Each main BIOS menu option is described in this manual.

The Main BIOS screen has two main frames. The left frame displays all the options that can be configured. “Grayed-out” options cannot be configured. The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it. (Note that BIOS has default text messages built in. We retain the option to include, omit, or change any of these text messages.) Settings printed in **Bold** are the default values.

A " ►" indicates a submenu. Highlighting such an item and pressing the <Enter> key will open the list of settings within that submenu.

The BIOS setup utility uses a key-based navigation system called hot keys. Most of these hot keys (<F1>, <F10>, <Enter>, <ESC>, <Arrow> keys, etc.) can be used at any time during the setup navigation process.

4-2 Main Menu

When you first enter AMI BIOS Setup Utility, you will see the Main setup screen. You can always return to the Main setup screen by selecting the **Main** tab on the top of the screen.

The Main Setup screen provides you with a system overview, which includes the version, built date and ID of the AMIBIOS, the type, speed and number of the processors in the system and the amount of memory installed in the system.

System Time/System Date

You can edit this field to change the system time and date. Highlight *System Time* or *System Date* using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in DAY/MM/DD/YYYY format. The time is entered in HH:MM:SS format. Please note that time is in a 24-hour format. For example, 5:30 A.M. appears as 05:30:00 and 5:30 P.M. as 17:30:00.

4-3 Advanced Settings Menu

▶ CPU Configuration Sub-Menu

Opening this submenu will display a list of CPU information as well as the following two settings.

GART Error Reporting

This setting is used for testing only.

MTRR Mapping

This determines the method used for programming CPU MTRRs when 4 GB or more memory is present. The options are **Continuous**, which makes the PCI hole non-cacheable, and **Discrete**, which places the PCI hole below the 4 GB boundary.

► IDE Configuration

Onboard PCI IDE Controller

The following options are available to set the IDE controller status: Disabled will disable the controller. **Primary** will enable the primary IDE controller. There is no Secondary option since only one IDE slot is provided on the board.

Primary IDE Master/Slave

Highlight one of the two items above and press <Enter> to access the submenu for that item.

Type

Select the type of device connected to the system. The options are Not Installed, **Auto**, CDROM and ARMD.

LBA/Large Mode

LBA (Logical Block Addressing) is a method of addressing data on a disk drive. In the LBA mode, the maximum drive capacity is 137 GB. For drive capacities of over 137 GB, your system must be equipped with 48-bit LBA mode addressing. If not, contact your manufacturer or install an ATA/133 IDE controller card that supports 48-bit LBA mode. The options are Disabled and **Auto**.

Block (Multi-Sector Transfer)

Block mode boosts IDE drive performance by increasing the amount of data transferred. Only 512 bytes of data can be transferred per interrupt if block mode is not used. Block mode allows transfers of up to 64 KB per interrupt. Select "Disabled" to allow the data to be transferred from and to the device one sector at a time. Select "Auto" to allow the data transfer from and to the device occur multiple sectors at a time if the device supports it. The options are **Auto** and Disabled.

PIO Mode

PIO (Programmable I/O) mode programs timing cycles between the IDE drive and the programmable IDE controller. As the PIO mode increases, the cycle time decreases. The options are **Auto**, 0, 1, 2, 3, and 4. Select Auto to allow AMI BIOS to auto detect the PIO mode. Use this value if the IDE disk drive support cannot be determined. Select 0 to allow AMI BIOS to use PIO mode

data transfer rate of 3.3 MBs. Select 1 to allow AMI BIOS to use PIO mode 1 for a data transfer rate of 5.2 MBs. Select 2 to allow AMI BIOS to use PIO mode 2 for a data transfer rate of 8.3 MBs. Select 3 to allow AMI BIOS to use PIO mode 3 for a data transfer rate of 11.1 MBs. Select 4 to allow AMI BIOS to use PIO mode 4 for a data transfer rate of 16.6 MBs. This setting generally works with all hard disk drives manufactured after 1999. For other disk drives, such as IDE CD-ROM drives, check the specifications of the drive.

DMA Mode

Select the DMA mode of the drive. Options are SWDMA0, SWDMA1, SWDMA2, MWDMA0, MWDMA1, MWDMA2, UDMA0, UDMA1 and UDMA2.

S.M.A.R.T.

Self-Monitoring Analysis and Reporting Technology (SMART) can help predict impending drive failures. Select "Auto" to allow BIOS to auto detect hard disk drive support. Select "Disabled" to prevent AMI BIOS from using the S.M.A.R.T. Select "Enabled" to allow AMI BIOS to use the S.M.A.R.T. to support hard drive disk. The options are Disabled, Enabled, and **Auto**.

32-Bit Data Transfer

Select "Enabled" to activate the function of 32-Bit data transfer. Select "Disabled" to deactivate the function. The options are Enabled and **Disabled**.

Hard Disk Write Protect

Select Enabled to enable the function of Hard Disk Write Protect to prevent data from being written to HDD. The options are Enabled or **Disabled**.

IDE Detect Time Out (Sec)

This feature allows the user to set the time-out value for detecting ATA, ATA PI devices installed in the system. The options are 0 (sec), 5, 10, 15, 20, 25, 30 and **35**.

ATA(PI) 80Pin Cable Detection

This setting allows AMI BIOS to auto-detect the 80-Pin ATA(PI) cable. The options are **Host & Device**, Host and Device.

► Floppy Configuration

Floppy A

Move the cursor to these fields via up and down <arrow> keys to select the floppy type. The options are Disabled, 360 KB 5 1/4", 1.2 MB 5 1/4", 720 KB 3 1/2", **1.44 MB 3 1/2"**, and 2.88 MB 3 1/2".

Floppy B

Move the cursor to these fields via up and down <arrow> keys to select the floppy type. The options are **Disabled**, 360 KB 5 1/4", 1.2 MB 5 1/4", 720 KB 3 1/2", 1.44 MB 3 1/2", and 2.88 MB 3 1/2".

► PCI/PnP Menu

Clear NVRAM

Select Yes to clear NVRAM during boot-up. The options are Yes and **No**.

Plug & Play OS

Select Yes to allow the OS to configure Plug & Play devices. (This is not required for system boot if your system has an OS that supports Plug & Play.) Select **No** to allow AMIBIOS to configure all devices in the system.

PCI Latency Timer

This option sets the latency of all PCI devices on the PCI bus. Select a value to set the PCI latency in PCI clock cycles. Options are 32, **64**, 96, 128, 160, 192, 224 and 248.

Allocate IRQ to PCI VGA

Set this value to allow or restrict the system from giving the VGA adapter card an interrupt address. The options are **Yes** and No.

Palette Snooping

Select "Enabled" to inform the PCI devices that an ISA graphics device is installed in the system in order for the graphics card to function properly. The options are Enabled and **Disabled**.

PCI IDE BusMaster

Set this value to allow or prevent the use of PCI IDE busmastering. Select "Enabled" to allow AMI BIOS to use PCI busmaster for reading and writing to IDE drives. The options are **Disabled** and Enabled.

Offboard PCI/ISA IDE Card

This option allows the user to assign a PCI slot number to an Off-board PCI/ISA IDE card in order for it to function properly. The options are **Auto**, PCI Slot1, PCI Slot2, PCI Slot3, PCI Slot4, PCI Slot5, and PCI Slot6.

IRQ3/IRQ4/IRQ5/IRQ7/IRQ9/IRQ10/IRQ11/IRQ14/IRQ15

This feature specifies the availability of an IRQ to be used by a PCI/PnP device. Select Reserved for the IRQ to be used by a Legacy ISA device. The options are **Available** and Reserved.

DMA Channel0/Channel1/Channel3/Channel5/Channel6/Channel7

Select Available to indicate that a specific DMA channel is available to be used by a PCI/PnP device. Select Reserved if the DMA channel specified is reserved for a Legacy ISA device. The options are **Available** and Reserved.

Reserved Memory Size

This feature specifies the size of memory block to be reserved for Legacy ISA devices. The options are **Disabled**, 16K, 32K and 64K.

► Super IO Configuration

Onboard Floppy Controller

Use this setting to **Enable** or Disable the onboard floppy controller.

Serial Port1 Address

This option specifies the base I/O port address and Interrupt Request address of serial port 1. Select "Disabled" to prevent the serial port from accessing any system resources. When this option is set to *Disabled*, the serial port physically becomes unavailable. Select "3F8/IRQ4" to allow the serial port to use 3F8 as its I/O port address and IRQ 4 for the interrupt address. The options are Disabled, **3F8/IRQ4**, 3E8/IRQ4 and 2E8/IRQ3.

Serial Port2 Address

This option specifies the base I/O port address and Interrupt Request address of serial port 2. Select "Disabled" to prevent the serial port from accessing any system resources. When this option is set to "Disabled", the serial port physically becomes unavailable. Select "2F8/IRQ3" to allow the serial port to use 2F8 as its I/O port address and IRQ 3 for the interrupt address. The options are Disabled, **2F8/IRQ3**, 3E8/IRQ4 and 2E8/IRQ3.

Serial Port 2 Mode

Tells BIOS which mode to select for serial port 2. The options are **Normal**, Sharp-IR, SIR and Consumer.

KBC Clock Source

The options for the KBC clock source are 8 MHz, **12 MHz** and 16 MHz.

Restore on AC Power Loss

This setting allows you to choose how the system will react when power returns after an unexpected loss of power. The options are Power Off and **Last State**.

Watch Dog Timer

This setting is used to enable or disabled the Watch Dog Timer function. It must be used in conjunction with the Watch Dog jumper (see Chapter 2). Options are **Disabled** and Enabled.

- ▶ **Chipset Menu**
- ▶ **North Bridge Configuration**
- ▶ **Memory Configuration**

Memclock Mode

This setting determines how the memory clock is set. **Auto** has the memory clock set by the code and Limit allows the user to set a standard value.

MCT Timing Mode

Sets the timing mode for memory. Options are **Auto** and Manual.

User Configuration Mode

Options are **Auto** and Manual.

Bank Interleaving

This setting is used to determine whether bank interleaving is to be employed. The options are **Auto** and Disabled.

Burst Length

Use this setting to set the memory burst length. 64-bit Dq must use 4 beats. Options are 8 beats, **4 beats** and 2 beats.

Enable Clock to All DIMMs

This setting allows the user to enable unused clocks to DIMMs, even if DIMM slots are empty. Options are Enabled and **Disabled**.

Hardware Memory Hole

When "Enabled", allows software memory remapping around the memory hole (only supported by rev. E0 processors and above). Options are Enabled and **Disabled**.

Node Interleaving

Use this setting to Enable or **Disable** node interleaving.

► ECC Configuration

DRAM ECC Enable

DRAM ECC allows hardware to report and correct memory errors automatically. Options are **Enabled** and Disabled.

MCA DRAM ECC Logging

When "Enabled", MCA DRAM ECC logging and reporting is enabled. Options are Enabled and **Disabled**.

ECC Chip Kill

Allows the user to Enable or **Disable** ECC Chip Kill.

DRAM Scrub Redirect

Allows system to correct DRAM ECC errors immediately, even with background scrubbing on. Options are Enabled and **Disabled**.

DRAM BG Scrub

Corrects memory errors so later reads are correct. Options are **Disabled** and various times in nanoseconds and microseconds.

L2 Cache BG Scrub

Allows L2 cache RAM to be corrected when idle. Options are **Disabled** and various times in nanoseconds and microseconds.

Data Cache BG Scrub

Allows L1 cache RAM to be corrected when idle. Options are **Disabled** and various times in nanoseconds and microseconds.

Memory Timing Parameters

Select **CPU Node0** or CPU Node1 to view the parameters for that node in the field below.

▶ HT2000 System I/O Configuration

EXB_B Split to 2 (x4)

Enable or **Disable** EXB_B Split to 2.

EXB_C Split to 2 (x4)

Enable or **Disable** EXB_C Split to 2.

▶ HT1000 SouthBridge Configuration

HIDE XIOAPIC PCI Functions

The options are **Yes** and No.

▶ S-ATA Configuration

HT-1000 S-ATA

Use this setting to **Enable** or Disable the on-chip SATA controller.

S-ATA Mode

Use this to select either **IDE**, MMIO or RAID as the SATA mode.

▶ ACPI Configuration

▶ Advanced ACPI Configuration

ACPI Version Features

Select which version of ACPI you wish to use. Options are **ACPI v. 1.0**, ACPI v. 2.0 and ACPI v. 3.0.

ACPI APIC Support

Select "Enabled" to allow the ACPI APIC Table Pointer to be included in the RSDT pointer list. The options are **Enabled** and Disabled.

ACPI OEMB Table

This setting when enabled will include an OEMB table pointer to pointer lists. Options are **Enabled** and Disabled.

Headless Mode

Select "Enabled" to activate the Headless Operation Mode through ACPI. The options are Enabled and **Disabled**.

▶ Event Log Configuration

View Event Log

Highlight this item and press <Enter> to view the contents of the event log.

Mark All Events as Read

Highlight this item and press <Enter> to mark the DMI events as read.

Clear Event Log

This setting will clear all event logs when set to "OK". The options are OK and **Cancel**.

Event Log Statistics

Highlight this item and press <Enter> to view details on the count of total unread events.

► Hyper Transport Configuration

CPU0: CPU1 HT Link Speed

The HT link will run at the speed specified in this setting if it is slower than or equal to the system clock and if the board is capable. Options are **Auto**, 200 MHz, 400 MHz, 600 MHz, 800 MHz and 1 GHz.

CPU0: CPU1 HT Link Width

The HT link will run at the width specified in this setting. Options are **Auto**, 2 bit, 4 bit, 8 bit and 16 bit.

CPU0: HT2000 HT Link Speed

The HT link will run at the speed specified in this setting if it is slower than or equal to the system clock and if the board is capable. Options are **Auto**, 200 MHz, 400 MHz, 600 MHz, 800 MHz and 1 GHz.

CPU0: HT2000 HT Link Width

The HT link will run at the width specified in this setting. Options are **Auto**, 2 bit, 4 bit, 8 bit and 16 bit.

HT2000: HT1000 HT Link Speed

The HT link will run at the speed specified in this setting if it is slower than or equal to the system clock and if the board is capable. Options are **Auto**, 200 MHz, 400 MHz, 600 MHz and 800 MHz.

HT2000: HT1000 HT Link Width

The HT link will run at the width specified in this setting. Options are **Auto**, 2 bit, 4 bit and 8 bit.

► MPS Configuration

MPS Revision

This setting allows the user to select the MPS revision level. The options are 1.1 and **1.4**.

▶ **PCI Express Configuration**

Active State Power Management

This setting is used to Enable or **Disable** the PCI Express L0s and L1 Link power states.

▶ **Remote Access Configuration**

Remote Access

Use this setting to Enable or **Disable** remote access. If Enabled is selected, you can select a Remote Access type.

▶ **USB Configuration**

This screen will display the module version and all USB enabled devices.

Legacy USB Support

Select "Enabled" to enable the support for USB Legacy. Disable Legacy support if there are no USB devices installed in the system. The options are **Enabled** and Disabled.

USB 2.0 Controller Mode

Select the controller mode for your USB ports. Options are HiSpeed and **FullSpeed**. (HiSpeed=480 Mbps, FullSpeed=12 Mbps).

BIOS EHCI Hand-Off

Enable or Disable a workaround for OS's without EHCI hand-off support.

▶ **System Health Monitor**

CPU Overheat Temperature

Use the "+" and "-" keys to set the CPU temperature threshold to between 65° and 90° C. When this threshold is exceeded, the overheat LED on the chassis will light up and an alarm will sound. The LED and alarm will turn off once the CPU temperature has dropped to 5 degrees below the threshold set. The default setting is **78° C**.

The other items in the submenu are all systems monitor displays for the following information:

CPU1 Temperature, CPU2 Temperature (for dual CPU systems), System Temperature, CPU1 Vcore, CPU2 Vcore (for dual CPU systems), +5 Vin, +12Vin, -12V Vcc, DDRA VTT, DDRB VTT, 1.2V for Hyper-Transport, 2.5V, 5V standby, 2.5V standby and battery voltage.

► **System Fan Monitor**

Fan Speed Control Modes

This feature allows the user to determine how the system will control the speed of the onboard fans. If the option is set to "3-pin fan", the fan speed is controlled based upon the CPU die temperature. When the CPU die temperature is higher, the fan speed will be higher as well. If the option is set to "4-pin", the fan speed will be controlled by the Thermal Management Settings pre-configured by the user with this setting. Select "3-pin" if your chassis came with 3-pin fan headers. Select "4-pin" if your chassis came with 4-pin fan headers. Select "Workstation" if your system is used as a Workstation. Select "Server" if your system is used as a Server. Select "Disable" to disable the fan speed control function to allow the onboard fans to continuously run at full speed (12V). The options are **1) Disable, Full Speed** and **2) Server Mode**.

FAN1 Speed through FAN10 Speed

The speeds of the onboard fans (in rpm) are displayed here.

4-4 Boot Menu

► **Boot Settings Configuration**

Quick Boot

If Enabled, this option will skip certain tests during POST to reduce the time needed for the system to boot up. The options are **Enabled** and Disabled.

Quiet Boot

If **Disabled**, normal POST messages will be displayed on boot-up. If Enabled, this display the OEM logo instead of POST messages.

Add-On ROM Display Mode

This setting controls the display of add-on ROM (read-only memory) messages. Select "**Force BIOS**" to allow the computer system to force a third party BIOS to display during system boot. Select "Keep Current" to allow the computer system to display the BIOS information during system boot.

Boot up Num-Lock

Set this to "On" to allow the Number Lock setting to be modified during boot up. The options are **On** and Off.

PS/2 Mouse Support

This setting is to specify PS/2 mouse support. The options are **Auto**, Enabled and Disabled.

Wait for 'F1' If Error

Enable to activate the Wait for F1 if Error function. The options are **Enabled** and Disabled.

Hit 'DEL' Message Display

Enable to display the message telling the user to hit the DEL key to enter the setup utility. The options are **Enabled** and Disabled.

Interrupt 19 Capture

Enable to allow ROMs to trap Interrupt 19. The options are Enabled and **Disabled**.

► Boot Device Priority

This feature allows the user to prioritize the sequence for the Boot Device with the devices installed in the system. The default settings (with generic names) are:

- 1st Boot Device – Removeable drive (e.g. floppy drive)
- 2nd Boot Device – CD/DVD
- 3rd Boot Device – Hard drive
- 4th Boot Device – LAN

▶ **Hard Disk Drives**

This feature allows the user to prioritize the Boot sequence from available hard drives.

▶ **Removable Drives**

This feature allows the user to specify the Boot sequence from available removable drives.

▶ **CD/DVD Drives**

This feature allows the user to specify the boot sequence from available CDROM drives.

Onboard SCSI Host RAID

Use this setting to Enable or **Disable** the onboard SCSI Host RAID.

Onboard NIC PXE Option ROM

Use this setting to **Enable** or Disable the onboard NIC PXE option ROM.

4-5 Security Menu

AMI BIOS provides a Supervisor and a User password. If you use both passwords, the Supervisor password must be set first.

Change Supervisor Password

Select this option and press <Enter> to access the sub menu, and then type in the password.

Change User Password

Select this option and press <Enter> to access the sub menu, and then type in the password.

Boot Sector Virus Protection

This option is near the bottom of the Security Setup screen. Select "Disabled" to deactivate the Boot Sector Virus Protection. Select "Enabled" to enable boot sector protection. When "Enabled", AMI BIOS displays a warning when any program (or virus) issues a Disk Format command or attempts to write to the boot sector of the hard disk drive. The options are Enabled and **Disabled**.

4-6 Exit Menu

Select the Exit tab from AMI BIOS Setup Utility screen to enter the Exit BIOS Setup screen.

Save Changes and Exit

When you have completed the system configuration changes, select this option to leave BIOS Setup and reboot the computer, so the new system configuration parameters can take effect. Select Save Changes and Exit from the Exit menu and press <Enter>.

Discard Changes and Exit

Select this option to quit BIOS Setup without making any permanent changes to the system configuration and reboot the computer. Select Discard Changes and Exit from the Exit menu and press <Enter>.

Discard Changes

Select this option and press <Enter> to discard all the changes and return to AMI BIOS Utility Program.

Load Optimal Defaults

To set this feature, select Load Optimal Defaults from the Exit menu and press <Enter>. Then Select "OK" to allow BIOS to automatically load the Optimal Defaults as the BIOS Settings. The Optimal settings are designed for maximum system performance, but may not work best for all computer applications.

Load Fail-Safe Defaults

To set this feature, select Load Fail-Safe Defaults from the Exit menu and press <Enter>. The Fail-Safe settings are designed for maximum system stability, but not maximum performance.

Appendix A

BIOS Error Beep Codes

During the POST (Power-On Self-Test) routines, which are performed each time the system is powered on, errors may occur.

Non-fatal errors are those which, in most cases, allow the system to continue the boot-up process. The error messages normally appear on the screen.

Fatal errors are those which will not allow the system to continue the boot-up procedure. If a fatal error occurs, you should consult with your system manufacturer for possible repairs.

These fatal errors are usually communicated through a series of audible beeps. The numbers on the fatal error list, on the following page, correspond to the number of beeps for the corresponding error. All errors listed, with the exception of Beep Code 8, are fatal errors.

POST codes may be read on the LEDs located beside the LAN port on the serverboard backplane. See the description of the POST code LEDs in Chapter 5.

A-1 AMIBIOS Error Beep Codes

| Beep Code | Error Message | Description |
|------------------|---------------------------------|---|
| 1 beep | Refresh | Circuits have been reset. (Ready to power up.) |
| 5 short, 1 long | Memory error | No memory detected in system |
| 8 beeps | Display memory read/write error | Video adapter missing or with faulty memory |

Notes

Appendix B

BIOS POST Checkpoint Codes

When AMIBIOS performs the Power On Self Test, it writes checkpoint codes to I/O port 0080h. If the computer cannot complete the boot process, diagnostic equipment can be attached to the computer to read I/O port 0080h.

B-1 Uncompressed Initialization Codes

The uncompressed initialization checkpoint codes are listed in order of execution:

| Checkpoint | Code Description |
|------------|--|
| D0h | The NMI is disabled. Power on delay is starting. Next, the initialization code checksum will be verified. |
| D1h | Initializing the DMA controller, performing the keyboard controller BAT test, starting memory refresh and entering 4 GB flat mode next. |
| D3h | Starting memory sizing next. |
| D4h | Returning to real mode. Executing any OEM patches and setting the Stack next. |
| D5h | Passing control to the uncompressed code in shadow RAM at E000:0000h. The initialization code is copied to segment 0 and control will be transferred to segment 0. |

B-2 Bootblock Recovery Codes

The bootblock recovery checkpoint codes are listed in order of execution:

| Checkpoint | Code Description |
|------------|--|
| E0h | The onboard floppy controller if available is initialized. Next, beginning the base 512 KB memory test. |
| E1h | Initializing the interrupt vector table next. |
| E2h | Initializing the DMA and Interrupt controllers next. |
| E6h | Enabling the floppy drive controller and Timer IRQs. Enabling internal cache memory. |
| Edh | Initializing the floppy drive. |
| Eeh | Looking for a floppy diskette in drive A:. Reading the first sector of the diskette. |
| Efh | A read error occurred while reading the floppy drive in drive A:. |
| F0h | Next, searching for the AMIBOOT.ROM file in the root directory. |
| F1h | The AMIBOOT.ROM file is not in the root directory. |
| F2h | Next, reading and analyzing the floppy diskette FAT to find the clusters occupied by the AMIBOOT.ROM file. |
| F3h | Next, reading the AMIBOOT.ROM file, cluster by cluster. |
| F4h | The AMIBOOT.ROM file is not the correct size. |
| F5h | Next, disabling internal cache memory. |
| FBh | Next, detecting the type of flash ROM. |
| FCh | Next, erasing the flash ROM. |
| FDh | Next, programming the flash ROM. |
| FFh | Flash ROM programming was successful. Next, restarting the system BIOS. |

B-3 Uncompressed Initialization Codes

The following runtime checkpoint codes are listed in order of execution.

These codes are uncompressed in F0000h shadow RAM.

| Checkpoint | Code Description |
|------------|--|
| 03h | The NMI is disabled. Next, checking for a soft reset or a power on condition. |
| 05h | The BIOS stack has been built. Next, disabling cache memory. |
| 06h | Uncompressing the POST code next. |
| 07h | Next, initializing the CPU and the CPU data area. |
| 08h | The CMOS checksum calculation is done next. |
| 0Ah | The CMOS checksum calculation is done. Initializing the CMOS status register for date and time next. |
| 0Bh | The CMOS status register is initialized. Next, performing any required initialization before the keyboard BAT command is issued. |
| 0Ch | The keyboard controller input buffer is free. Next, issuing the BAT command to the keyboard controller. |
| 0Eh | The keyboard controller BAT command result has been verified. Next, performing any necessary initialization after the keyboard controller BAT command test. |
| 0Fh | The initialization after the keyboard controller BAT command test is done. The keyboard command byte is written next. |
| 10h | The keyboard controller command byte is written. Next, issuing the Pin 23 and 24 blocking and unblocking command. |
| 11h | Next, checking if <End or <Ins> keys were pressed during power on. Initializing CMOS RAM if the Initialize CMOS RAM in every boot AMIBIOS POST option was set in AMIBCP or the <End> key was pressed. |
| 12h | Next, disabling DMA controllers 1 and 2 and interrupt controllers 1 and 2. |
| 13h | The video display has been disabled. Port B has been initialized. Next, initializing the chipset. |
| 14h | The 8254 timer test will begin next. |
| 19h | Next, programming the flash ROM. |
| 1Ah | The memory refresh line is toggling. Checking the 15 second on/off time next. |
| 2Bh | Passing control to the video ROM to perform any required configuration before the video ROM test. |
| 2Ch | All necessary processing before passing control to the video ROM is done. Looking for the video ROM next and passing control to it. |
| 2Dh | The video ROM has returned control to BIOS POST. Performing any required processing after the video ROM had control |
| 23h | Reading the 8042 input port and disabling the MEGAKEY Green PC feature next. Making the BIOS code segment writable and performing any necessary configuration before initializing the interrupt vectors. |
| 24h | The configuration required before interrupt vector initialization has completed. Interrupt vector initialization is about to begin. |

| Checkpoint | Code Description |
|------------|---|
| 25h | Interrupt vector initialization is done. Clearing the password if the POST DIAG switch is on. |
| 27h | Any initialization before setting video mode will be done next. |
| 28h | Initialization before setting the video mode is complete. Configuring the monochrome mode and color mode settings next. |
| 2Ah | Bus initialization system, static, output devices will be done next, if present. See the last page for additional information. |
| 2Eh | Completed post-video ROM test processing. If the EGA/VGA controller is not found, performing the display memory read/write test next. |
| 2Fh | The EGA/VGA controller was not found. The display memory read/write test is about to begin. |
| 30h | The display memory read/write test passed. Look for retrace checking next. |
| 31h | The display memory read/write test or retrace checking failed. Performing the alternate display memory read/write test next. |
| 32h | The alternate display memory read/write test passed. Looking for alternate display retrace checking next. |
| 34h | Video display checking is over. Setting the display mode next. |
| 37h | The display mode is set. Displaying the power on message next. |
| 38h | Initializing the bus input, IPL, general devices next, if present. See the last page of this chapter for additional information. |
| 39h | Displaying bus initialization error messages. See the last page of this chapter for additional information. |
| 3Ah | The new cursor position has been read and saved. Displaying the Hit message next. |
| 3Bh | The Hit message is displayed. The protected mode memory test is about to start. |
| 40h | Preparing the descriptor tables next. |
| 42h | The descriptor tables are prepared. Entering protected mode for the memory test next. |
| 43h | Entered protected mode. Enabling interrupts for diagnostics mode next. |
| 44h | Interrupts enabled if the diagnostics switch is on. Initializing data to check memory wraparound at 0:0 next. |
| 45h | Data initialized. Checking for memory wraparound at 0:0 and finding the total system memory size next. |
| 46h | The memory wraparound test is done. Memory size calculation has been done. Writing patterns to test memory next. |
| 47h | The memory pattern has been written to extended memory. Writing patterns to the base 640 KB memory next. |
| 48h | Patterns written in base memory. Determining the amount of memory below 1 MB next. |
| 49h | The amount of memory below 1 MB has been found and verified. |
| 4Bh | The amount of memory above 1 MB has been found and verified. Checking for a soft reset and clearing the memory below 1 MB for the soft reset next. If this is a power on situation, going to checkpoint 4Eh next. |

| Checkpoint | Code Description |
|------------|--|
| 4Ch | The memory below 1 MB has been cleared via a soft reset. Clearing the memory above 1 MB next. |
| 4Dh | The memory above 1 MB has been cleared via a soft reset. Saving the memory size next. Going to checkpoint 52h next. |
| 4Eh | The memory test started, but not as the result of a soft reset. Displaying the first 64 KB memory size next. |
| 4Fh | The memory size display has started. The display is updated during the memory test. Performing the sequential and random memory test next. |
| 50h | The memory below 1 MB has been tested and initialized. Adjusting the displayed memory size for relocation and shadowing next. |
| 51h | The memory size display was adjusted for relocation and shadowing. |
| 52h | The memory above 1 MB has been tested and initialized. Saving the memory size information next. |
| 53h | The memory size information and the CPU registers are saved. Entering real mode next. |
| 54h | Shutdown was successful. The CPU is in real mode. Disabling the Gate A20 line, parity, and the NMI next. |
| 57h | The A20 address line, parity, and the NMI are disabled. Adjusting the memory size depending on relocation and shadowing next. |
| 58h | The memory size was adjusted for relocation and shadowing. Clearing the Hit message next. |
| 59h | The Hit message is cleared. The <WAIT...> message is displayed. Starting the DMA and interrupt controller test next. |
| 60h | The DMA page register test passed. Performing the DMA Controller 1 base register test next. |
| 62h | The DMA controller 1 base register test passed. Performing the DMA controller 2 base register test next. |
| 65h | The DMA controller 2 base register test passed. Programming DMA controllers 1 and 2 next. |
| 66h | Completed programming DMA controllers 1 and 2. Initializing the 8259 interrupt controller next. |
| 67h | Completed 8259 interrupt controller initialization. |
| 7Fh | Extended NMI source enabling is in progress. |
| 80h | The keyboard test has started. Clearing the output buffer and checking for stuck keys. Issuing the keyboard reset command next. |
| 81h | A keyboard reset error or stuck key was found. Issuing the keyboard controller interface test command next. |
| 82h | The keyboard controller interface test completed. Writing the command byte and initializing the circular buffer next. |
| 83h | The command byte was written and global data initialization has completed. Checking for a locked key next. |
| 84h | Locked key checking is over. Checking for a memory size mismatch with CMOS RAM data next. |
| 85h | The memory size check is done. Displaying a soft error and checking for a password or bypassing WINBIOS Setup next. |

| Checkpoint | Code Description |
|------------|--|
| 86h | The password was checked. Performing any required programming before WINBIOS Setup next. |
| 87h | The programming before WINBIOS Setup has completed. Uncompressing the WINBIOS Setup code and executing the AMIBIOS Setup or WINBIOS Setup utility next. |
| 88h | Returned from WINBIOS Setup and cleared the screen. Performing any necessary programming after WINBIOS Setup next. |
| 89h | The programming after WINBIOS Setup has completed. Displaying the power on screen message next. |
| 8Ch | Programming the WINBIOS Setup options next. |
| 8Dh | The WINBIOS Setup options are programmed. Resetting the hard disk controller next. |
| 8Fh | The hard disk controller has been reset. Configuring the floppy drive controller next. |
| 91h | The floppy drive controller has been configured. Configuring the hard disk drive controller next. |
| 95h | Initializing the bus option ROMs from C800 next. See the last page of this chapter for additional information. |
| 96h | Initializing before passing control to the adaptor ROM at C800. |
| 97h | Initialization before the C800 adaptor ROM gains control has completed. The adaptor ROM check is next. |
| 98h | The adaptor ROM had control and has now returned control to BIOS POST. Performing any required processing after the option ROM returned control. |
| 99h | Any initialization required after the option ROM test has completed. Configuring the timer data area and printer base address next. |
| 9Ah | Set the timer and printer base addresses. Setting the RS-232 base address next. |
| 9Bh | Returned after setting the RS-232 base address. Performing any required initialization before the Coprocessor test next. |
| 9Ch | Required initialization before the Coprocessor test is over. Initializing the Coprocessor next. |
| 9Dh | Coprocessor initialized. Performing any required initialization after the Coprocessor test next. |
| 9Eh | Initialization after the Coprocessor test is complete. Checking the extended keyboard, keyboard ID, and Num Lock key next. Issuing the keyboard ID command next. |
| A2h | Displaying any soft errors next. |
| A3h | The soft error display has completed. Setting the keyboard typematic rate next. |
| A4h | The keyboard typematic rate is set. Programming the memory wait states next. |
| A5h | Memory wait state programming is over. Clearing the screen and enabling parity and the NMI next. |
| A7h | NMI and parity enabled. Performing any initialization required before passing control to the adaptor ROM at E000 next. |
| A8h | Initialization before passing control to the adaptor ROM at E000h completed. Passing control to the adaptor ROM at E000h next. |

| Checkpoint | Code Description |
|------------|--|
| A9h | Returned from adaptor ROM at E000h control. Performing any initialization required after the E000 option ROM had control next. |
| Aah | Initialization after E000 option ROM control has completed. Displaying the system configuration next. |
| Abh | Uncompressing the DMI data and executing DMI POST initialization next. |
| B0h | The system configuration is displayed. |
| B1h | Copying any code to specific areas. |
| 00h | Code copying to specific areas is done. Passing control to INT 19h boot loader next. |

Notes