





SUPERMICRO® SuperServer 5019S-W4TR Quick Reference Guide




Jumpers and Connectors

Jumper	Description	Default Setting
JBR1	BIOS Recovery	Pins 1-2 (Normal)
JBT1	Clear CMOS	Open (Normal)
JI2C1/JI2C2	SMB to PCI Slots	Pins 1-2 (Enabled)
JNVME1	NVMe Enable/Disable	Pins 2-3 (Auto)
JPB1	BMC Enable/Disable	Pins 1-2 (Enabled)
JPG1	VGA Enable/Disable	Pins 1-2 (Enabled)
JPL1	LAN1/LAN2 Enable/Disable	Pins 1-2 (Enabled)
JPL2	LAN3/LAN4 Enable/Disable	Pins 1-2 (Enabled)
JPME2	Manufacturing Mode Select	Pins 1-2 (Normal)
JWD1	Watch Dog	Pins 1-2 (Reset)

Beep Code

BIOS Beep (POST) Codes		
Beep Code	Error Message	Description
1 beep	Refresh	Ready to boot
5 short,1 long	Memory error	No memory detected in system
5 beeps	No con-in or con-out devices	Con-in includes USB or PS/2 keyboard, PCI or serial console redirection, and IPMI KVM or SOL. Con-out includes the video controller, PCI or serial console redirection, and IPMI SOL
1 beep per device	Refresh	1 beep for each US device detected




Jumpers and Connectors


LED	Description	Status
LED1	Rear UID LED	Blue: On; Unit Identified
LED2	Power LED	Green: Solid On; Power On
LED3	Standby Power LED	Green: Solid On; Standby Power On
Connector		
COM1/COM2	COM Port/COM Header	
FAN1 ~ FAN6	System/CPU Fan Headers	
IPMI LAN	Dedicated IPMI Gigabit (RJ45) Port	
I-SATA0 ~ I-SATA5	SATA 3.0 Connectors via Intel PCH (6Gb/s)	
I-SGPIO 1/2	Serial Link General Purpose I/O Headers for I-SATA 3.0 connections (I-SGPIO1 for I-SATA0~3, I-SGPIO2 for I-SATA4~5)	
J3	M.2 Socket 3 (supports 2260, 2280, 22110 for NVMe)	
JBAT1	Onboard Battery	
JD1	Speaker/Buzzer Header (Pins 1-4: Speaker, Pins 3-4: Buzzer)	
JF1	Front Control Panel Header	
JF2	Activity LED Header for LAN3/LAN4	
JIPMB1	4-pin External BMC I2C Header (for an IPMI Card)	
JL1	Chassis Intrusion Header	
JLED1	3-pin Power LED Indicator Header	
JPI2C1	Power I2C System Management Bus (Power SMB) Header	
JPW1	24-pin ATX Main Power Connector (Required)	
JPW2	+12V 8-pin CPU Power Connector (Required)	
JSD1/JSD2	SATA Disk On Module (DOM) Power Connectors	
JSTBY1	Standby Power Header	
JSXB1A/1B/1C	SMC Proprietary WIO_L (Left) Add-On Card Slot	
JTPM1	Trusted Platform Module (TPM)/Port 80 Connector	
JUIDB1	UID (Unit Identification) Switch	
LAN1/LAN2/LAN3/LAN4	10 Gigabit (RJ45) LAN Ports	
SP1	Internal Speaker/Buzzer	
USB 0/1	Back Panel USB 2.0 Ports	
USB 2/3, USB 4/5	Front Accessible USB 2.0 Headers	
USB 6/7	Back Panel USB 3.0 Ports	
USB 8	Front Accessible USB 3.0 Type-A Header	
USB 9/10	Front Accessible USB 3.0 Header	
VGA	Back Panel VGA Port	

CPU Installation

- Remove the cover plate that protects the CPU#1 socket: press the load lever to release the load plate, which covers the CPU socket, from its locked position.
- Gently lift the load lever to open the load plate. Remove the plastic cover plate.



- Use your thumb and your index finger to hold the edges of the processor. Align the CPU key (the semi-circle cutouts) with the socket keys.



- Once aligned, carefully place the processor into the socket. Do not drop the processor on the socket, move or rub the processor against the socket or against any socket pins, which may damage the components.



- Carefully press the processor load lever down until it locks into its retention tab.






- Place the heatsink on top of the CPU so that the four mounting holes are aligned with those on the heatsink retention mechanism.



- Screw in two diagonal screws (i.e. the #1 and the #2 screws) until they are just snug. Do not fully tighten the screws or you may damage the CPU.



- Add the two remaining screws then finish the installation by fully tightening all four screws (be careful not to overtighten).



For more information go to : <http://www.supermicro.com/support>