



SUPERMICR[®] SuperStorage L-Series Quick Reference Guide

Board Layout



No.	Description
1	JBOD Expansion Port/Cable
2	CPU1 Slot2 PCI-E 3.0 x8
3	CPU2 Slot3 PCI-E 3.0 x8
4	CPU2 Slot4 PCI-E 3.0 x8
5	CPU2 Slot5 PCI-E 3.0 x8
6	CPU1 Slot6 PCI-E 3.0 x8
7	P1-DIMMA1(Blue)/P1-DIMMA2 slot
8	P1-DIMMB1 (Blue)/P1-DIMMB2 slot
9	P1-DIMMC1 (Blue)/P1-DIMMC2 slot
10	P1-DIMMD1 (Blue)/P1-DIMMD2 slot
11	P2-DIMME1 (Blue)/P2-DIMME2 slot
12	P2-DIMMF1 (Blue)/P2-DIMM F2 slot
13	P2-DIMMG1 (Blue)/P2-DIMM G2 slot
14	P2-DIMMH1 (Blue)/P2-DIMM H2 slot
15	CPU1 / P1 install first / minimum requirement
16	CPU2/P2
17	SATA 3 Ports 0~1 (from Intel PCH)
18	SATA 2 Ports 2~5 (from Intel PCH)
19	SAS 2.0 ports 0~3, 4~7 (from LSI SAS 2308 Controller)
20	JBT1 = CMOS Reset
21	SATA DOM Power

MEMORY



DIMM Module Population Tables

Processors and their Corresponding Memory Slots

CPU#	Corresponding Memory Slot											
CPU 1 (P1-)	A1	B1	C1	D1	A2	B2	C2	D2	A3	B3	C3	D3
CPU2 (P2-)	E1	F1	G1	H1	E2	F2	G2	H2	E3	F3	G3	H3

Processor and Memory Module Population


Number of CPUs+DIMMs	CPU and Memory Population Configuration Table (For memory to work properly, please install DIMMs as shown below.)
1 CPU & 3 DIMMs	CPU1 P1-A1/P1-B1/P1-C1
1 CPU & 6 DIMMs	CPU1 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2
1 CPU & 9 DIMMs	CPU1 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2/P1-C2/P1-D2/P1-A3
1 CPU & 12 DIMMs	CPU1 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2/P1-C2/P1-D2/P1-A3/P1-B3/P1-C3/P1-D3
2 CPUs & 6 DIMMs	CPU1 + CPU2 P1-A1/P1-B1/P1-C1 P2-E1/P2-F1/P2-G1
2 CPUs & 12 DIMMs	CPU1 + CPU2 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2 P2-E1/P2-F1/P2-G1/P2-H1/P2-E2/P2-F2
2 CPUs & 16 DIMMs	CPU1 + CPU2 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2/P1-C2/P1-D2 P2-E1/P2-F1/P2-G1/P2-H1/P2-E2/P2-F2/P2-G2/P2-H2
2 CPUs & 18 DIMMs	CPU1 + CPU2 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2/P1-C2/P1-D2/P1-A3 P2-E1/P2-F1/P2-G1/P2-H1/P2-E2/P2-F2/P2-G2/P2-H2/P2-E3
2 CPUs & 24 DIMMs	CPU1/CPU2 P1-A1/P1-B1/P1-C1/P1-D1/P1-A2/P1-B2/P1-C2/P1-D2/P1-A3/P1-B3/P1-C3/P1-D3 P2-E1/P2-F1/P2-G1/P2-H1/P2-E2/P2-F2/P2-G2/P2-H2/P2-E3/P2-F3/P2-G3/P2-H3

Please refer to the user manual for more details on memory types, speeds and configurations

Chassis Front Panel LED Indicator Definition

Component	State/Indication
Power	Solid Green/Power is On
Onboard SATA	Flash Green/Onboard SAS/SATA Drive Activity
LAN1	Flash Green/Network Connectivity
LAN2	Flash Green/Network Connectivity
Temperature/Fan	Flash Red/Fan Failure; Solid Red/Over Temperature
Power Failure	Flash Red/Power Supply Failure


LED Indicator



Drive RED LED Indicator

LED State	Indication
OFF	Normal Operation
Solid ON	Drive Failure
Slow Blink (1 Hz)	Rebuilding to Drive
2 Fast Blink, Pause (repeats)	Drive Assigned as a Hot Spare
Fast Blink (4 Hz)	Slot Identify command has been issued from controller

Rear View



No.	Description
1	COM Port1
2	Dedicated IPMI LAN
3	USB 0/1/2/3 Ports
4	LAN 1/2/3/4 Ports
5	VGA Port
6	UID Button
7	Up to 5x open PCI-E expansion slots*
8	Dual JBOD Expansion port**


*Low profile PCI slots shown, models: SSG-6037R-E1R16L & SSG-6046R-E1R24L feature full height half length expansion slots

**SSG-6027R-E1R12L features a single expansion port


Beep Codes

BIOS Beep Codes		
Beep Code/LED	Message	Description
1 beep	Refresh	Circuits have been reset. (Ready to power up)
5 short beeps + 1 long beep	Memory	No memory detected
5 long beeps + 2 short beeps	Display memory read/write status	Video adapter missing or with faulty memory
1 continuous beep	System	System overheat

CPU Installation



Heatsink Installation



- Place heatsink on top of installed CPU
- Line up the four screws to socket
- Push down the heatsink and screw down as shown (cross pattern, in order: A, C, B, D)
- NOTE: Only use 6-8 lb/f of torque; otherwise, hand-tighten each screw, to avoid damaging the system

Caution

SAFETY INFORMATION
IMPORTANT: See installation instructions and safety warning before connecting system to power supply.
http://www.supermicro.com/about/policies/safety_information.cfm

WARNING:
To reduce risk of electric shock/damage to equipment, disconnect power from server by disconnecting all power cords from electrical outlets.
If any CPU socket empty, install protective plastic CPU cap

CAUTION:
Always be sure all power supplies for this system have the same power output. If mixed power supplies are installed, the system will not operate.

For more information go to :
<http://www.supermicro.com/support>

