



SAS Controller Card

AOC-S3616L-L16iT



USER'S MANUAL

Revision 1.0

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this manual, please see our website at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL Super Micro Computer, Inc. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".



WARNING: This product can expose you to chemicals including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.

Manual Revision 1.0

Release Date: July 25, 2018

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2018 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Preface

About this Manual

This manual is written for professional system integrators and PC technicians. It provides information for the installation and use of the controller card. Installation and maintenance should be performed by experienced technicians only.

All images and layouts shown in this user's guide are based upon the latest PCB revision available at the time of publishing. The card you have received may or may not look exactly the same as the graphics shown in this user's guide. This manual may be periodically updated without notice. Please check the Supermicro website for possible updates to the manual revision level.

Notes

If you have any questions, contact our support team at: support@supermicro.com.

Warnings

Special attention should be given to the following symbols used in this manual.



Warning! Indicates important information given to prevent equipment/property damage or personal injury.



Warning! Indicates high voltage may be encountered when performing a procedure.

Contents

Chapter 1 Introduction

1.1 Overview.....	6
1.2 Unpacking the System	6
1.3 System Features	6
1.4 Connectors and Indicators	7

Chapter 2 Installation

2.1 Static-Sensitive Devices.....	8
Precautions	8
Unpacking	8
2.2 Installing the Controller Card	9
2.4 Installing the Drivers in Windows	10

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.
Tel: +1 (408) 503-8000
Fax: +1 (408) 503-8008
Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)
Website: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands
Tel: +31 (0) 73-6400390
Fax: +31 (0) 73-6416525
Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)
Website: www.supermicro.nl

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235
Taiwan (R.O.C)
Tel: +886-(2) 8226-3990
Fax: +886-(2) 8226-3992
Email: support@supermicro.com.tw
Website: www.supermicro.com.tw

Chapter 1

Introduction

1.1 Overview

The Supermicro SAS AOC-S3616L-L16iT internal controller card features sixteen internal SAS3 ports with four internal min-SAS HD connectors. It utilizes a Broadcom SAS3616 SAS3 controller chip and features a 1.2 GHz processor. The AOC-S3616L-L16iT can provide support for JBOD systems of up to 1024 devices. It is streamlined to meet the growing demand for increased data throughput and scalability requirements across the enterprise-class server platforms. It is a low power and cost-effective near-line storage solution that delivers maximum performance and reliability.

1.2 Unpacking the Card

Inspect the box in which the product was shipped and note if it was damaged. If any equipment appears damaged, file a claim with the carrier who delivered it.

1.3 System Features

The following is an overview of the main features.

System Features	
General	Gen3 PCI Express x16 Broadcom SAS3616 SAS3 controller Sixteen internal SAS3 ports with four mini-SAS HD connectors 1.2 GHz processor HBA supports 1024 devices Supports JBOD Enlarged venting hole for improved airflow Supports 12, 6 and 3 Gb/s SAS and 6 and 3 Gb/s SATA data transfer rates Operates up to 45°C
OS Support	Windows 2012 and 2008; RedHat Enterprise and SUSE Linux
Power Consumption	15.1 Watts
Physical Dimensions	Low-profile (L x H) 6.1" x 2.7 " (15.5 cm x 6.9 cm)

1.4 Connectors and Indicators




Figure 1-1. Layout

Components		
Item	Feature	Description
1	SAS Connector	SAS 0 – 3
2	SAS Connector	SAS 4 – 7
3	SAS Connector	SAS 8 – 11
4	SAS Connector	SAS 12 – 15
5	MDIO (J7)	Header (manufacturer use only)
6	UART0 (J5)	Debug port (manufacturer use only)
7	JP1	Internal test (engineering use only)
8	SBL_DIS (JP2)	Boot loader (manufacturer use only)
9	FAULT_LED	System fault LED: Solid ON red when system fault occurs
10	HB_LED	Heart beat LED: Blinking green indicates firmware is loaded and running on the controller chip

Chapter 2

Installation

2.1 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your controller card, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the controller card from the antistatic bag.
- Handle the expansion card by its edges only; do not touch its components or peripheral chips.
- Put the controller card back into the antistatic bags when not in use.
- For grounding purposes, make sure that your system chassis provides excellent conductivity between the power supply, the case, the mounting fasteners and the controller card.

Unpacking

The controller card is shipped in antistatic packaging to avoid static damage. When unpacking your component, make sure you are static protected.

Note: To avoid damaging your components and to ensure proper installation, be sure to always connect the power cord last, and always remove it before adding, removing or changing any hardware components.

2.2 Installing the Controller Card

Depending upon which system configuration is used, a riser card may or may not be required .

Installing the Controller Card

1. Power down the system, remove the power cords from the rear of the power supply and remove the system cover.
2. Verify that the PCI-E chassis slots in your system are low-profile. If your system has full-height PCI-E slots, replace the low-profile bracket on your card with a full-height bracket.
3. Insert the controller card into a x16 PCI-E slot.
4. Connect the mini-SAS HD cables from the controller card to either the direct attached storage target devices or the cable sockets on the backplanes.
5. The cable latch will click into the locked position when connected properly.
6. Replace the system cover, plug in the power cord and power up the system.




Figure 2-1. Connecting the Cables

2.4 Installing the Drivers in Windows

Refer to the instructions that came with your controller card and follow the manufacturer's recommended steps for installing the operating system driver. Download the latest drivers from the Supermicro project board at <https://www.supermicro.com/wftp/driver/SAS/LSI/3616>.