


SUPERMICR[®] SuperServer[®] SYS-E50-14AM/-L/-N5 Quick Reference Guide



MNL-2786-QRG-100

© 2025 Supermicro Computer Inc. All rights reserved. Reproduction of this document, whether in part or in whole, is strictly prohibited without Supermicro's written consent. All trademarks are property of their respective entities. All information provided is deemed accurate at the time of printing, however, it is not guaranteed.


Front Features: SYS-E50-14AM




Front Features: SYS-E50-14AM-L




Front Features: SYS-E50-14AM-N5




Rear Features: SYS-E50-14AM and SYS-E50-14AM-N5




Rear Features: SYS-E50-14AM-L




Motherboard Layout (Top)



Motherboard Layout (Bottom)



I/O Panel



I/O Ports			
Item	Description	Item	Description
1	LAN1	4	USB2 (3.2)
2	LAN2	5	USB1 (3.2)
3	HDMI	6	DC Jack

Product Pages

SYS-E50-14AM



SYS-E50-14AM-L



SYS-E50-14AM-N5

