

## BIOS Release Notes Form

*Supermicro disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade. All products, computer systems, dates, and figures specified are preliminary based on current expectations, and are subject to change without notice. Supermicro and the Supermicro logo are trademarks of Super Micro Computer, Inc. in the U.S. and/or other countries. Copyright © 2018 Super Micro Computer, Inc. All rights reserved.*

<b>Product Name</b>	<b>H12SSW-iNL/NTL (All)</b>
<b>Release Version</b>	<b>2.0</b>
<b>Release Date</b>	<b>02/22/2021</b>
<b>BIOS Date</b>	<b>02/22/2021</b>
<b>Previous Version</b>	<b>1.3</b>
<b>Update Category</b>	<b>Critical</b>
<b>Dependencies</b>	<b>N/A</b>
<b>Important Notes</b>	<b>ECO #25168</b> <b>BIOS image: BIOS_H12SSWL-1B98_20210222_2.0_STDsp.bin</b> <b>Please update BIOS with attached Flash Utility in package.</b>
<b>Enhancements</b>	1. [Rome/Milan BIOS] Change BIOS revision to 2.0. 2. [Milan BIOS] Update AGESA MilanPI to 1.0.0.1. 3. [Milan BIOS] Update A011 GN B1 microcode 0A001119. 4. [Rome BIOS] Update AGESA RomePI to 1.0.0.A. 5. [Rome/Milan BIOS] Fix IPV6 disable in the IPMI GUI but BIOS initialize will appear IPV6 address.
<b>New features</b>	<b>N/A</b>
<b>Fixes</b>	<b>N/A</b>

***Release Notes from Previous Release(s)***

Revision 1.0 (2020/11/25)

First release.