

## IPMI Release Notes Form

*Supermicro disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade. All products, computer systems, dates, and figures specified are preliminary based on current expectations, and are subject to change without notice. Supermicro and the Supermicro logo are trademarks of Super Micro Computer, Inc. in the U.S. and/or other countries. Copyright © 2018 Super Micro Computer, Inc. All rights reserved.*

<b>Product Name</b>	<b>X12SPL-(LN4)F</b>
<b>Release Version</b>	<b>1.03.08</b>
<b>Build Date</b>	<b>10/17/2023</b>
<b>Previous Version</b>	<b>1.03.05</b>
<b>Update Category</b>	<b>Recommended</b>
<b>Dependencies</b>	<b>None</b>
<b>Important Notes</b>	<b>None</b>
<b>Enhancements</b>	<b>None</b>
<b>New features</b>	<b>None</b>
<b>Fixes</b>	<ol style="list-style-type: none"><li><b>1. Fixed fan fail feature broken from 01.03.01 to 01.03.06.</b></li><li><b>2. [IPMI ECO 01.03.07] UID LED should be blinking but kept solid on when using Web UI UID Control.</b></li></ol>