



# SUPERMICR® SuperBlade® SBI-612B-(1,5)NE34 Quick Reference

## Front Features



## System Features: Front


Features	Description
Control Panel	Power button and status indicators
Release Levers	Levers for two latches that secure the blade in the enclosure
Expansion Slots	Up to two PCIe Gen5 cards
Service Tag	Pull-out identifier (with BMC ADMIN default password sticker)
Storage Drives	Bays for four E3.S hot-swap drives



## Control Panel Features

Feature	State	Description
Power Button		The main power switch applies or removes primary power from the power supply to the server but maintains standby power.
Power LED	Green	Power On
	Amber, steady	Power Off
KVM/UID LED	Amber, blinking	Before the BMC is ready, blinks until every node is ready.
	Blue, steady	Indicates that KVM has been initialized.
NIC Activity LED	Blue, blinking	Unit Identifier indicator (The UID function is activated with a management program.)
	Green, flashing	Indicates traffic (Tx and RX data) on the LAN connection to this blade module.
System Fail LED	Orange, flashing	Indicates traffic over the network (when present in the system).
	Red	Indicates a fatal error. This may be a memory error, a VGA error, or any other fatal error that prevents the operating system from booting.

## Top Features



## System Features: Top

Feature	Description
DIMM Slots	Sixteen memory slots
M.2 Slot	One M.2 SSD
Processor	One Intel® Xeon® 6700/6500-series processors with P-cores or E-cores with heatsink
PCIe Slots	Up to two PCIe Gen5 cards

## BMC Password

Each system comes with a unique default password for the ADMIN user. This can be found on a sticker on the motherboard and another on the chassis service tag. If necessary, the password can be reset.

For more information, please visit <https://www.supermicro.com/en/solutions/management-software/bmc-resources>

## Product Pages




Blade SBI-612B-1NE34



Blade SBI-612B-5NE34

## System Block Diagram



MNL-2747-QRG-100

© 2025 Supermicro Computer Inc. All rights reserved. Reproduction of this document, whether in part or in whole, is strictly prohibited without Supermicro's written consent. All trademarks are property of their respective entities. All information provided is deemed accurate at the time of printing, however, it is not guaranteed.