

SUPERMICRO® SuperServer 5018A-MHN4 Quick Reference Guide

Board Layout

No.	Description
1	Slot4 PCI-E 2.0 x4
2	Slot6 PCI-E 2.0 x8
3	JTPM1 = Trusted Platform Module (TPM)/Port 80 Connector
4	JSD1 = SATA DOM Power Connector
5	JBT1 = CMOS Clear
6	CPU1
7	DIMMB1(DBlue)/DIMMB2
8	DIMMA1(DBlue)/DIMMA2
9	I-SATA0 ~ I-SATA5 = SATA Ports 0~5

MEMORY

Unbuffered (UDIMM) DDR3 Memory				
DIMM Slots per Channel	DIMMs Populated per Channel	DIMM Type	POR Speeds	Memory Population Sequence
2	1	Unbuffered DDR3 DIMM	1600,1333	A1, B1 (2 DIMMs)
2	2	Unbuffered DDR3 DIMM	1600,1333	A1, B1, A2, B2 (4 DIMMs)

Note: Use memory modules of the same type, speed, frequency and size.

DIMMA1 (Blue Slot) DIMMA2
DIMMB1 (Blue Slot) DIMMB2

Beep Codes

BIOS Error Beep Codes		
Beep Code/LED	Error Message	Description
1 beep	Refresh	Circuits have been reset. (Ready to power up)
5 short beeps + 1 long beep	Memory error	No memory detected in the system
8 beeps	Display memory read/write error	Video adapter missing or with faulty memory
OH LED On	System OH	System Overheat

Rear View

No.	Description
1	PCI-E Expansion Slot (w/riser card)
2	UID
3	VGA Port
4	GbE LAN1/2 Port
5	GbE LAN3/4 Port
6	USB 0/1/2/3 Ports
7	COM1 Port
8	Dedicated LAN for IPMI
9	Single/Redundant Power Supply Module

Front View & Interface

No.	Description
1	Power Button
2	Reset Button
3	Power LED
4	Device Activity LED
5	LAN1 LED & LAN2 LED
6	Information LED
7	Hard Drive Signal
8	Hard Drive Fail

SATA Drive Installation

Mounting a Drive in a Drive Carrier

The SATA drives are mounted in drive carriers to simplify their installation and removal from the chassis. These carriers also help promote proper airflow for the system. For this reason, even empty carriers without drives installed must remain in the chassis.

1. Install a new drive into the carrier with the printed circuit board side facing down so that the mounting holes align with those in the carrier.
2. Secure the drive to the carrier with six screws, as shown.

Caution

SAFETY INFORMATION
IMPORTANT: See installation instructions and safety warning before connecting system to power supply.
http://www.supermicro.com/about/policies/safety_information.cfm

WARNING:
To reduce risk of electric shock/damage to equipment, disconnect power from server by disconnecting all power cords from electrical outlets.
If any CPU socket empty, install protective plastic CPU cap

CAUTION:
Always be sure all power supplies for this system have the same power output. If mixed power supplies are installed, the system will not operate.

CAUTION:
The fans on the A1SRM-2758F are not hot-swappable.
For more information go to :
<http://www.supermicro.com/support>

<http://www.supermicro.com>

MNL-1579-QRG